SONY. AUTO SET-UP ADAPTOR BKM-1450

OPERATION AND MAINTENANCE MANUAL 2nd Edition
Serial No. 2000301 and Higher

For the customers in the USA

Warning—This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Important—To insure that the complete system (including this peripheral) is capable of complying with the FCC requirements, it is recommended that the user make sure that the individual equipment of the complete system has a label with one of the following statements.

"This equipment has been tested with a Class A Computing Device and has been found to comply with Part 15 of FCC rules."

-or-

"This equipment complies with the requirements in Part 15 of FCC rules for a Class A Computing Device."

-or equivalent.

For the customers in Canada

This apparatus complies with the Class A limits for radio noise emissions set out in Radio Interference Regulations.

Pour les utilisateurs au Canada

Cet appareil est conforme aux normes Classe A pour bruits radioélectriques, spécifiés dans le Règlement sur le brouillage radioélectrique.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK

ON THE SCHEMATIC DIAGRAMS, EXPLODED
VIEWS AND IN THE PARTS LIST ARE CRITICAL TO
SAFE OPERATION. REPLACE THESE COMPONENTS
WITH SONY PARTS WHOSE PART NUMBERS APPEAR
AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS
PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT
ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE
REPLACED OR IMPROPER OPERATION IS SUSPECTED.

CAUTION!!

DO NOT USE THE EXTERNAL DEGAUSSER TO DEMAGNETIZE THE SCREEN.
BE SURE TO USE THE DEGAUSS SWITCH ON THE FRONT PANEL.

ご注意

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

CONFIDENTIAL

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

CONFIDENTIEL

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

VERTRAULICH

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

ATTENTION AU COMPOSANT AYANT RAPPORT A LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UN TRAMÉ ET UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES, LES VUES EXPLOSÉES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DU CIRCUIT QUI SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNMENT SONT IDENTIFIÉS DANS CE MANUEL. SUIVRE LES PROCÉDURES QUAND LES COMPOSANTS CRITIQUES SONT REMPLACÉS OU LE FONCTIONNEMENT IMPROPRE EST SUSPECTÉ.

ATTENTION!!

NE PAS UTILISER DE DÉMAGNÉTISEUR EXTÉRITUR POUR DÉMAGNÉTISER L'ÉCRAN. UTILISER LA TOUCH DE DÉMAGNÉTISATION (DEGAUSS) SUR LE PANNEAU FRONTAL.

目 次 TABLE OF CONTENTS

1.	取り扱い操作	1.	OPERATION
1-1. 1-1-2. 1-1-3. 1-4. 1-1-5. 1-1-6. 1-7. 1-8 1-9 1-10.	概要 1-1(J) 1-1. オートセットアップの概要 1-1(J) 1-2. 本機の構成 1-1(J) 取り付け 1-2(J) 2-1. コントロールパネルとHE基板の 取り付け 1-3(J) オートセットアップ部の名称と機能 1-5(J) オートセットアップ部の名称と機能 1-5(J) オートクロマ/フェーズ調整 1-6(J) 4-1. 基準カラーバー信号 1-6(J) 4-2. モニターの準備 1-6(J) 4-3. オートクロマ/フェーズ調整 1-7(J) 4-4. マニュアルクロマ/フェーズ調整 1-7(J) 4-4. マニュアルクロマ/フェーズ調整 1-11(J) 5-1. 色温度の記憶 1-11(J) 5-2. オートホワイトバランス調整 1-11(J) 5-3. 色温度の選択 1-20(J) カラーアナライザー機能 (BKM-2053使用時のみ) 1-21(J) サービスマンモード 1-24(J) ア-1. 色温度D9300Kの場合の輝度の選択 1-24(J) エラーメッセージ 1-25(J) オートセットアップフローチャート 1-27(J) -9-1. オートセットアップ 1-27(J) -9-2. サービスマンモード 1-33(J) 0. 主な仕様 1-35(J)	1-1. 1-1-1. 1-1-2. 1-2. 1-2-1. 1-2-2. 1-3. 1-4. 1-4-1 1-4-2 1-4-3 1-4-4 1-5. 1-5-1 1-5-2 1-5-3 1-6. 1-7. 1-7-1 1-8. 1-9. 1-9-1 1-9-2 1-10. 1-11.	Parts list
1-1	1. 梱包1-36(J)		

2.	挿入時の基板配置図 2-1(J)	5.	ADJUSTMENTS
 3. 3. 	BOARD ARRANGEMENT DIAGRAM WHEN INSERTING 2-1(E) 基板の取り付け 3-1(J) INSTALLATION 3-1(E)	5-1. 5-1-1 5-1-2 5-1-3 5-2. 1.	. Connection
4. 4-1. 4-1 4-1	-2. Auto White Balance ······ 4-1(J)	2. 3. 4. 5. 6.	Adjustment of Sample Hold Position 5-3(E) Adjustment of Blue Level 5-3(E) Adjustment of D/A Converter 5-4(E) Adjustment of Window Pulse Width 5-5(E) Adjustment of Output Level 5-6(E) DIAGRAMS
4-1. 4-1. 4-1- 4-1-	2. Auto White Balance 4-1(E)	6-1. 6-1. 6-2. 6-2.	半導体外形図 6-1 Semiconductors 6-1 回路図, プリント図 6-2 Mounting and Schematic Diagrams 6-2 BN Board 6-3 BO Board 6-7 BP Board 6-11 HE Board 6-15 梱包図 7-1
4-1- 4-1- 4-1-	4. Pulse Gne and D/A Converter (Bo Board)	8. 8.	電気部品表
5.	調整方法		
5-1	準備 5-1(J) 1-1. SWのセッティング 5-1(J) 1-2. 接続方法 5-2(J) 1-3. 基板主要部品配置図 5-2(J) 調整方法 5-3(J) キャラクター表示位置調整 5-3(J) サンプルホールド位置調整 5-3(J) BLUE LEVELの調整 5-3(J) D/A コンバーター調整 5-4(J) Window Pulse幅調整 5-5(J) 出力レベル調整 5-6(J)		

第1章 取り扱い操作

1-1. 概要

1-1-1. オートセットアップの概要

本機はソニーカラービデオモニターBVM-1410/1310/1410Pにオートセットアップ機能を追加するための基板セットです。

オートクロマ/フェーズ調整

色相 (クロマフェーズ), 飽和度 (クロマゲイン), ブライトネス, コントラスト, セットアップレベルを, 外部からのカラーバー信号を基準として自動的に基準レベルに調整します。

この機能により、多数のモニター(オートセットアップ機 能搭載)が簡単に短時間で調整できます。

オートホワイトバランス調整

別売りのソニーオートセットアッププローブBKM-2053またはBKM-2052を使用し、プローブに記憶させた基準白色に合わせてモニターのホワイトバランス調整を自動的に行います。

プローブには、工場出荷時に記憶させてある9300°K(日本以外の地域では6500°K)の標準色温度以外にも任意の3種類の色温度をカラービデオモニターから読みとって記憶させることができます。このため、各局独自の微妙なホワイトバランス調整も、いったん色温度を記憶させておくと、簡単に行えます。(メモリー保持期間100年以上)1台のプローブで、複数のモニターの色温度を合わせることができます。

色温度の選択

本体内に4つのメモリーを持ち、4種類の色温度を記憶させることができます。メモリーはバックアップされており、電源を切ってもデータは保持されます。一度調整した色温度はメモリーされ、プローブを使わなくても、このメモリーを呼び出すだけで記憶されている色温度に設定することができます。

カラーアナライザー機能 (BKM-2053使用時のみ)

プローブBKM-2053でモニター画面の白色データ(R, G, B)を読みとり、基準白色との比率を%で画面に表示します。この数字を目安に、オートホワイトバランス調整範囲になるようモニターの輝度、コントラスト調整を行ったり、オートセットアップ機能のないモニターのホワイトバランス調整を行うことができます。

メニュー選択方式による簡単操作

オートセットアップの操作手順,調整結果などはすべて画面上に表示されます。

1-1-2. 本機の構成

本機は、次の部品で構成されています。 基板ブロック (BN, BO, BP基板) (1) HE基板 (1) コントロールパネル (1) 接続ケーブル (8ピンコネクターつき) (1)


モニターの改造について

BVM-1310シリアルNo.0010001~0010250 は本機を取り付ける前に改造が必要です。詳しくは第2章以降をご覧ください。


1-2. 取り付け

1-2-1. コントロールパネルとHE基板の 取り付け


1 モニターの右ドロアーを引き出し、コントロールパネルをはずします。




2 HE基板をはずします。




3 本機に付属のHE基板にステップ 2 ではずしたコネクターを接続します。



- **4** ステップ2ではずしたねじ4本を使ってHE基板を取り付けます。
- **5** 線材を、基板とシャーシの下側に押し込んで整理します。




6 ステップ1ではずしたねじ4本を使って、本機に付属のコントロールパネルを取り付けます。




1-2-2. 基板ブロックの取り付け

- **1** モニターの上面キャビネットをはずします。(はずしかたは、本マニュアルの第2章を参照)
- 2 右側面のB1~BJに入っている基板をすべて引き出します。




- **3** BA基板を半分引き出し、TB基板の上方奥から接続されていないコネクター3個を引き出します。BA基板は元どおり差し込みます。
- **4** RGB/コンポーネントアダプターBKM-1440を装着 していない場合のみ,TB基板下方から接続されてい ないコネクターを3個引き出します。*
- **5** TB-15 (BIスロットの奥にある) から, 8 ピン黄コネクターをはずします。




* BKM-1440を装着してある場合は、この3個のコネクターはすでにBF基板に接続されています。この接続を変える必要はありません。BP-5端子には何も接続する必要がありません。


6 ステップ 3 ではずした10ピン赤コネクターと12ピン黄 コネクターを基板ブロックのBO-3端子とBN-2端子へ




7 基板ブロックをB4とB5のスロットに奥までしっかり 差し込みます。



- **8** ステップ4ではずした2ピン黄コネクターをBP-5端子へ*, ステップ5ではずした8ピン黄コネクターをBP-2端子へ接続します。
- **9** 付属の接続ケーブルでBP-3端子とTB-15端子を接続 します。




10 コードクランパーで、コード類を処理します。



11 B1~BJに基板を元どおり差し込みます。 以前にB4, B5に基板が入っていた場合には、モニター の説明書を参照して適切な位置へ入れ換えてください。

1-3. オートセットアップ部の名称と機能

コントロールパネル(右ドロアー内部)



1 RESET (リセット) キー

オートセットアップ操作の途中,いつでも,このキーを押すと初期状態に戻ります。

2 ENT (入力) キー

オートセットアップ中、このキーを押すとその直前の操作が有効となり、次の操作ステップへ進めます。 オートセットアップを開始するときにも押します。

3 ESC (エスケープ) キー

ENTキー操作を取り消して前の操作ステップに戻すときに押します。自動調整中は受けつけません。

④ ⇔ (カーソル) キー

画面上に現れるカーソルの位置を動かすのに使います。押 すたびにカーソルが画面下方へと動きます。最下段に達す ると最上段に戻ります。

(する) * (アステリスク) キー

モニターに記憶した色温度を呼び出すときに使います。 カラーアナライザー機能で、プローブのメモリー位置を選 択するときにも使います。

PEOBE (プローブ) 端子

別売りのプローブBKM-2053またはBKM-2052を接続します。

1-4. オートクロマ/フェーズ調整

基準カラーバー信号をモニターに入力して,色相(クロマフェーズ),飽和度(クロマゲイン),ブライトネス,コントラスト,セットアップレベルを自動的に基準レベルに調整します。

1-4-1. 基準カラーバー信号

オートクロマ/フェーズ調整に使用できるカラーバー信号は、ビデオ信号の種類(コンポジット、RGB、コンポーネント)およびカラー方式(NTSC、PAL、SECAM)によって異なります。

Ş	表有例: 第一次	TOP TO SHOULD BE SEEN THE SHOP OF THE SHOP		
コン	NTSC	FULL FIELD: ホワイト100%/飽和度75%/セットアップ0~100% またはホワイト75%/飽和度75%/セットアップ0~100% SMPTE/SPLIT		
ポジ	PAL	100 BARS: ホワイト100%/飽和度100% (FULL FIELD)		
ッ	PAL-M	EBU BARS: ホワイト100%/飽和度75%(FULL FIELD)		
	SECAM	100 BARS: ホワイト100%/飽和度100/75%(FULL FIELD)		
	SECAM	75 BARS: ホワイト75%/飽和度75% (FULL FIELD)		
		100 BARS: ホワイト100%/飽和度100/75% (FULL FIELD)		
RO	GB	75 BARS: ホワイト75%/飽和度75% (FULL FIELD)		
		5/10 STEPS: ステアステップ5または10		
ם	ンポーネント	100 BARS: ホワイト100%/飽和度100/75%(FULL FIELD) 75 BARS: ホワイト75%/飽和度75%(FULL FIELD)		

1-4-2. モニターの準備

モニターのスイッチ類を次のように設定します。

前面パネル

- MODEセレクター→AUTO (押し込まない)
- SCAN MODE ① (Hディレイ), ⊖ (Vディレイ) スイッチ→OFF (押し込まない)
- CONTRAST, BRIGHTNESS, CHROMA, PHASE MANUALスイッチ→プリセット位置 (押し込まない)

HB基板(右ドロアー内部)

- PIC. SET UP POSITIONコントロール→中央位置
- MATRIXスイッチ→OFF

入力の選択


前面のINPUTセレクターとHB基板のINPUT SELECT ボタン, COLOR STANDARDボタンを入力信号のカラー 方式とビデオ信号の種類*に応じて設定します。

* 各信号を受像するには、その信号に応じたデコーダー基板が必要です。詳しくはモニターの説明書をご覧ください。

1-4-3. オートクロマ/フェーズ調整

基準カラーバー信号がコンポジット信号の場合

1 ENTキーを押します。



2 ◆ (カーソル) キーを押して「AUTO CHROMA/PHASE」を選びます。



ENTキーを押します。

3 ◆ キーを押して、使用する基準カラーバー信号を選びます。 ビデオ信号とカラー方式によって、選べるカラーバーが違います。「1-4-1.基準カラーバー信号」参照。



AUTO CHROMA/PHASE

■FULL FIELD
SMPTE/SPLIT

-SELECT & PRESS ENT-




ENTキーを押します。

4 オートクロマ/フェーズ調整が行われます。

調整中, 画面はブルーオンリーモードになります。




調整が終わると下のメッセージが出ます。 (約1 秒後 に消えます。) NTSCの例



* SECAMの場合は、色相は調整されませんので「-」が表示されます。

基準カラー バー信号がRGBまたはコンポーネント信号の場合

1 ENTキーを押します。



2 → (カーソル) キーを押してシステムを選びます。

COMPONENT: コンポーネント信号

RGB: RGB信号



ENTキーを押します。

3 ◇キーを押して、使用する基準カラーバー信号を選びます。 ビデオ信号とカラー方式によって、選べるカラーバーが違います。「1-4-1.基準カラーバー信号」参照。

COMPONENT BARS

■100 BARS 75 BARS SMPTE/SPLIT

-SELECT & PRESS ENT-

または

RGB BARS

■100 BARS 75 BARS 5/10 STEPS

-SELECT & PRESS ENT-



ENTキーを押します。


4 オートクロマ/フェーズ調整が行われます。

調整中、画面はブルーオンリーモードになります。



調整が終わると下のメッセージが出ます。(約1秒後に消えます。)


コンポーネントの例



- * コンポーネントの場合は,色相は調整されませんので「-」が表示されます。
- ** RGBの場合は色相と飽和度は調整されませんので「-」が表示されます。

調整ができない場合

●モニター前面のMANUALスイッチが押し込まれている とステップ1でENTキーを押したとき、下の画面が現 れます。



MANUALスイッチを押して元に戻してから, ENTキーをもう一度押してください。

●カラーバー信号の選択が違っていると, ステップ4の調整終了後, 調整できなかった項目に「NG」が出ます。

PHRSE : OK
CHROMA : OK
BRT.CAL : OK
CDNT.CAL : NG
SETUP : OK

ESCキーを押すとステップ3の画面に戻ります。正しい信号を選び直してからENTキーを押してください。

各カラー方式ごとに基準カラーバー信号を入力して上記の手順でオートクロマ/ フェーズ調整を行うと、調整結果がモニターのメモリーに記憶されます。こうし てセットアップしておけば後でCOLOR STANDARDボタンを切り換えるだけで 各システムのセットアップ状態に自動的に調整されます。 NTSC メモリー PAL COLOR STANDARD メモリー BVM-1410/1310/1410P ボタン、 SECAM INPUT SELECT デコーダー メモリー COMPONENT RGB/COMPONENTボタン メモリー RGB メモリー

1-4-4. マニュアルクロマ/フェーズ調整

本機を装着した場合,通常はオートクロマ/フェーズ調整を行いますが,オート調整に設定されていると,モニター前面のコントロールで調整できる範囲が狭くなります。不都合な場合には,次のようにしてマニュアル調整(本機を装着しない場合と同じ)に戻します。

1 *キーを押します。

SELECT MONITOR MEM

■M-D9300 (EBU)

M-MEM1

M-MEM2

-SELECT & PRESS ENT-

2 ENTキーを押します。

AUTO: オートクロマ/フェーズ調整

MANUAL:マニュアルクロマ/フェーズ調整

CHROMA/PHASE

MANUAL.

-SELECT & PRESS ENT-

3 ◆ キーを押して「MANUAL」を選びます。


4

ENTキーを押します。 モニター画面のメニュー表示が消えます。 これでMANUALに切り換わります。

ご注意

クロマ/フェーズのコントロール回路は右図のような構成 PRESETコントロール になっており、AUTO、MANUALのどちらに設定されて いてもPRESETコントロールが機能します。オートクロマ/フェー ズ調整を行った後でPRESETコントロールを動かす と、調整がずれてしまいますのでご注意ください。

クロマ/フェーズ DDDCCTTコントコ



1-5 オートホワイトバランス調整

ホワイトバランス調整はコンポジット信号で行ってください。RGB, コンポーネント信号モードではオートホワイトバランス調整はできませんが, コンポジット信号で合わせたホワイトバランスは, RGB, コンポーネント信号使用時に「SELECT MONITOR MEM」モード(「1-5-3. 色温度の選択」参照)で読み出すことができます。

オートホワイトバランス調整の前に

- ●外光の影響を避けるため、できるだけ周囲光がさえぎられるところで調整を行ってください。
- ランディングがずれていると調整の誤差が大きくなります。前もって調整しておいてください。
- 着磁の影響を避けるため、DEGAUSSスイッチを使って 消磁しておいてください。

1-5-1. 色温度の記憶

プローブBKM-2053またはBKM-2052には、工場出荷時に、6500°Kまたは9300°Kの色温度が記憶させてあります。これに加えて、3種類までの任意の色温度をプローブに記憶させることができます。必要に応じて、この記憶させた色温度を基準としてオートホワイトバランス調整ができます。

準備

- 基準カラーバー信号を使ってオートクロマ/フェーズ調整を済ませておきます。


プロープのパージョン

プローブのバージョンとモニターの蛍光体の組み合わせが 一致しないと、正しい色温度の白が再現されない場合があ ります。次の表で確認してください。


	Arri Kaled	工量出荷房C配值合 3/13/08/5温度
BKM-2052-01	SMPTE	D6500°K
-02	EBU	D6500°K
- 03	EBU	D9300°K
BKM-2053-01	SMPTE	D6500°K
-02	EBU	D6500°K
-03	EBU	D9300°K

プローブの接続

BVM-1410/1310/1410P本体の色温度を記憶する場合



基準モニター (オートセットアップ機能なし) の色温度を 記憶する場合



この接続をするとBVM-1410/1310/1410Pから基準信号 が基準モニターへ供給されます。オートセットアップのメッセージはBVM-1410/1310/1410Pの画面に表示されます。

基準モニターについて

- 基準モニターにはBVM-1410/1310/1410Pと同じ蛍光体を使ったものを使用ください。
- BKM-2052使用時は、SCREENスイッチのある基準モニターをご使用ください。
- 基準 ε まない。 IN端子は ε ながない。
- 基準モニターとBVM-1410/1310/1410Pの明るさが大幅に異なると色温度の記憶ができない場合があります。 基準モニターのBRIGHTNESS, CONTRASTコントロールで画面の明るさを大体そろえておいてください。

蛍光体色度

BVM-1310

(SMPTE)

	X	Y
レッド	0.630	0.340
グリー	ン 0.310	0.595
ブルー	0.155	0.070

誤差: ±0.005以下

BVM-1410/1410P


(EBU)

	X	Y
レッド	0.640	0.330
グリーン	0.290	0.600
ブルー	0.150	0.060

誤差: ±0.005以下

プロープBKM-2053使用時の操作

1 ENTキーを押します。



2 カーソルが「MEMORIZE COL. TEMP」の位置にあることを確認します。


違う場合は ひ キーを押して動かします。




ENTキーを押します。

プローブが正しく接続されていない場合は、「CONNECT PROBE」のメッセージが現れます。正しく接続して ください。

◆ キーを押して「P-MEM1」~「P-MEM3」の任意のメモリー位置を選びます。



4 モニター画面にプローブを吸着させます。



5 白色の画面のまま色温度が読みとられ、プローブに記憶されます。 記憶が終わると下の画面が現れます。(約1秒後にステップ3の画面に戻ります。)

PROCEDURE COMPLETED!


ご注意

色情報の記憶ができない場合は画面に「OUT OF RANGE」の点滅とともにエラーメッセージが出ます。「1-8. エラーメッセージ」を参照して処置を行った後、モニターのオートセットアップ部のいずれかのキー(RESET以外)を押てからやり直してください。

プロープBKM-2052使用時の操作

SBVMモニター本体の色温度を記憶する場合。

1 ENTキーを押します。



2 カーソルが「MEMORIZE COL. TEMP」の位置にあることを確認します。

違う場合は ◆ キーを押して動かします。



ENTキーを押します。

プローブが接続されていない場合は、「CONNECT PROBE」のメッセージが現れます。接続して、ENTキーを押してください。

3 ◆ キーを押して「P-MEM1」~「P-MEM3」の任意のメモリー位置を選びます。

MEMORIZE COL.TEMP

■P-MEM1 P-MEM2

P-MEM2

-SELECT & PRESS ENT-



ENTキーを押します。

4 モニターの画面にプローブを吸着させます。

SET PROBE ON CRT

---PRESS ENT---



ENTキーを押します。

12.4	BVMモニター本体の色温度を記憶する場合。	選手モニターの色温度を配復する場合: 第二十二
5	下の画面が現れます。	
	SET RE	ED ONLY
6	ENTキーを押します。 赤のビームだけが自動的にONになり,赤の情報が記憶されます。 記憶が終わると下のメッセージが現れます。 SET GREEN ONLY	6 基準モニターのSCREENスイッチでRED(赤)のビームだけをONにします。
		7 ENTキーを押します。 暗い赤と明るい赤を測定して赤の情報が記憶されます。 記憶が終わると下のメッセージが現れます。 SET GREEN ONLY

	BVMモニター本体の色温度を記憶する場合	基準モニターの色温度を記憶する場合	
7	ENTキーを押します。 緑のビームだけが自動的にONになり、緑の情報が記憶されます。 記憶が終わると下のメッセージが現れます。	基準モニターのSCREENスイッチでGREEN(緑)の ビームだけをONにします。ENTキーを押します。 緑の情報が記憶されると、下のメッセージに変わります。	
	SET BLUE ONLY	SET BLUE ONLY	
8	ENTキーを押します。 者のビームだけが自動的にONになり,青の情報が記	10 基準モニターのSCREENスイッチでBLUE (青) のビムだけをONにします。	
	憶されます。 記憶が終わると下のメッセージが現れます。 (約1秒後にステップ3の画面に戻ります。)	11 ENTキーを押します。 青の情報の記憶が終わると下のメッセージが出ます (約1秒後にステップ3の画面に戻ります。)	- 0
	PROCEDURE COMPLETED!	PROCEDURE COMPLETED!	
	これで色温度がプロープに記憶されました。	これで色温度がプローブに記憶されました。	

ご注意

色情報の記憶ができない場合は画面に「OUT OF RANGE」の点滅とともにエラーメッセージが出ます。「1-8. エラーメッセージ」を参照して処置を行った後、モニターのオートセットアップ部のいずれかのキー(RESET以外)を押してからやり直してください。

1-5-2. オートホワイトバランス調整

プローブに記憶した色温度を基準として自動的にホワイト バランス調整を行います。

プローブへの色温度の記憶のしかたは「1-5-1. 色温度の記憶」をご覧ください。

準備

- ◆ホワイトバランスをとりたいモニター(オートセットアップ機能付き)のPROBE端子へプローブを接続します。
- ホワイトバランスをとりたいモニターでオートクロマ/ フェーズ調整を済ませておきます。
- ●1-11(J)ページの「オートホワイトバランス調整の前に」 をお読みください。

操作

■ ENTキーを押します。

MONITOR AUTO SETUP


■ AUTO CHROMA/PHASE
SETUP THIS MONITOR
MEMORIZE COL.TEMP
ANALYZE COL.TEMP

(NTSC)

- SELECT & PRESS ENT
カーソル


2 カーソルが「SET UP THIS MONITOR」の位置にあることを確認します。

違う場合は ひ キーを押して動かします。



プローブが接続されていない場合は、「CONNECT PROBE」のメッセージが現れます。接続して、ENTキーを押してください。

3 → キーを通して、基準にしたい色温度が記憶してあるプローブのメモリー位置を選びます。



ENTキーを押します。

| 5 外光の測定を行うために画面はまず暗くなり,次にオートホワイトバランス調整が行われます。 調整が終わると(BKM-2053の場合約30秒,BKM-2052の場合約60秒)下の画面が現れます。 約1 秒後に消えます。

| PROCEDURE COMPLETED!

- ●自動調整中に調整を中止する場合はRESETキーを押します。 調整は取り消され、初期画面に戻ります。
- ●調整ができない場合は、画面に「OUT OF RANGE」の点滅とともにエラーメッセージが出ます。「1-8. エラーメッセージ」を参照して処置を行った後、モニターのオートセットアップ部のいずれかのキー(RESET以外)を押してからやり直してください。


上記の操作でオートホワイトバランス調整を行うと、基準の色温度がモニター内部の同じメモリー位置に記憶されます。(Γ 1-5-3.色温度の選択」参照)


1-5-3. 色温度の選択

「SET UP THIS MONITOR」のメニューでオートホワイトバランス調整(「1-5-2. オートホワイトバランス調整」参照)を行うと、オートホワイトバランス調整に使用した基準白色の色温度がモニターの同じメモリー位置に自動的に記憶されます。

いったんこのようにして色温度を記憶しておくと,プローブを使わなくても,メモリーを呼び出すだけで記憶された 色温度に設定することができます。

また、モニターのドロアー内のGAIN/BIAS ADJUSTコントロールを使って、マニュアルでホワイトバランス調整をすることもできます。





- 2 → キーを押して,希望の色温度のメモリー位置を選びます。
 - M-D9300 (またはM-D6500), M-MEM 1, M-MEM 2, M-MEM 3: モニターは, 選んだメモリー位置に記憶されている色温度に自動的に設定されます。

MANUAL: GAIN/BIAS ADJUSTコントロールでホワイトバランス調整をします。

3 ESCキーを押します。 モニター画面のメニュー表示が消えます。

ご注意


上記の画面で、「M-MEM 1」のM-は、モニターのメモリーであることを示します。これに対し、「SETUP THIS MONITOR」メニューなどで表示される「P-MEM 1」は、プローブのメモリーを示します。オートホワイトバランス調整後は、プローブのメモリーに記憶した色温度は、同じ番号のモニターのメモリーを呼び出すことにより設定できます。

1-6. カラーアナライザー機能(BKM-2053 使用時のみ)


プローブBKM-2053をモニター画面に吸着して、赤、緑、青の色情報を読み取り、プローブに記憶されている基準データとの比率を%で表示することができます。また輝度もFL(フートランバート)で表示されます。オートセットアップ機能のないモニターのホワイトバランスを調整したり、色温度記憶時に「OUT OF RANGE」のエラーの原因を確かめて輝度を調整し直したりするのに便利です。

プロープの接続

BVM-1410/1310/1410P本体の色情報を検出する場合



オートセットアップ機能なしのモニターの色情報を検出する場合



この接続をするとBVM-1410/1310/1410Pから基準信号 が他のモニターへ供給されます。色情報はBVM-1410/ 1310/1410Pの画面に表示されます。

操作

1 ENTキーを押します。 MONITOR AUTO SETUP ■AUTO CHROMA/PHASE SETUP THIS MONITOR MEMORIZE COL.TEMP ANALYZE COL.TEMP ーカラー方式 (NTSC) ◄ -SELECT & PRESS ENT-カーソル 2 カーソルが「ANALYZE COL.TEMP」の位置にあることを確認します。 違う場合は ❖ キーを押して動かします。 ENTキーを押します。 プローブが接続されていない場合は、「CONNECT PROBE」のメッセージが現れます。接続して、ENTキー を押してください。 3 モニター画面にプローブを吸着させます。 SET PROBE ON CRT ---PRESS ENT---4 ENTキーを押します。 基準データ表示 -(D9)(R=100 G=100 B=100) 基準データとの比較(%) (「MEMORIZE COL.TEMP」メニュー R:赤 G:緑 でプローブに記憶した色温度) プローブのメモリー位置が表示される B:青 D9: D9300 (またはD6: D6500) HIGH (40.0FL) M1: MEM-1 M2: MEM-2 明部/暗部表示(◆ キーで選択) 輝度 (fL) M3: MEM-3

HIGH:明部(100%白) LOW:暗部(20%白) 5 基準データを変更する場合のみ、*キーを押します。

SELECT PROBE MEM

■P-D9300 (EBU)
P-MEM1
P-MEM2
P-MEM3

-SELECT & PRESS ENT-



◆ キーでメモリー位置を選んでから、ENTキーを押します。

- 6 ◆ キーを押して「HIGH (明部)」の情報を読み取るか「LOW (暗部)」の情報かを選びます。 ◆ キーを押すたびにHIGHとLOWが切り換わります。
- 7 ENTキーを押します。

選んだ明部または暗部の色情報が読み取られ、画面に表示されます。

D9 R=100 G=100 B=100

40.0FL

HIGH

- 8 「HIGH」か「LOW」,もう一方の情報を見るときは, ❖ キーで切り換えます。
- ●「ANALYZE COL.TEMP」モードから抜けるにはESCキーを押します。ステップ1の画面に戻ります。


色情報の表示について

プローブで検出できる輝度範囲は、HIGHのとき $0.0 \sim 59.0$ fL, LOWのとき $0.0 \sim 2.0$ fLです(D9300 KまたはD6500 K にて)。輝度がこれ以上の場合は、数字の代わりに「---」が表示されます。

LOWまたはHIGHのいずれかで「---」表示になる場合は,色温度の記憶($\lceil 1-5-1$. 色温度の記憶」参照)を行っても $\lceil \text{OUT OF RANGE} \rfloor$ の表示が出て色温度が記憶できません。


1-7. サービスマンモード

RESET+ーとESCキーを押すとサービスマンモードになります。 このモードには5つのメニューがあります。



「4:2:2 INSTALLATION」メニューは、本機をデジタル入力のあるモニター*に取り付けたときのみ使用します。 「INITIAL LUMINANCE」メニューは、色温度をD9300K にしたときの輝度を選択します。

1-7-1. 色温度 D9300Kの場合の輝度の選択



1-8. エラーメッセージ

オートクロマ/フェーズ調整時

海 示	原。因	处 注置 计
NG	カラーバーの選択が正しくない。	正しく選択し直す。
	入力信号が終端されていない。	終端器をつける。
SET UP: NG	モニターのPIC. SET UP POSITIONコン	中央位置にする。
	トロールが中央位置に設定されていない。	

オートホワイ トバランス調整時

表示	原。因	処 置
PROBE NOT CONNECTED!	プローブがPROBE端子に正しく接続され	正しく接続する。
	ていない。	
OUT OF RANGE	基準モニターの明部の輝度が低すぎてプロー	基準モニターのCONTRASTコントロール
**LUMINANCE (HIGH) **TOO LOW FOR PROBE	ブに記憶できない。	で輝度を上げる。
OUT OF RANGE	基準モニターの暗部の輝度が低すぎてプロー	基準モニターのBRIGHTNESSコントロー
*LUMINANCE (LOW) *TOO LOW FOR PROBE	ブに記憶できない。	ルで輝度を上げる。
OUT OF RANGE	基準モニターの明部の輝度が高すぎてプロー	基準モニターのCONTRASTコントロール
*LUMINANCE (HIGH) *TOO HIGH FOR PROBE	ブに記憶できない。	で輝度を下げる。
OUT OF RANGE	基準モニターの暗部の輝度が高すぎてプロー	基準モニターのBRIGHTNESSコントロー
米LUMINANCE (LOW) 米TOO HIGH FOR PROBE	ブに記憶できない。	ルで輝度を下げる。
OUT OF RANGE	プローブに記憶されている輝度レベルが低	モニター前面のBRIGHTNESSコントロー
*BIAS CONTROL *MINIMUM LIMIT	いため、暗部のホワイトバランス調整がで	ルで輝度を下げる。
WMMMMOM Billing	きない。	
OUT OF RANGE	プローブに記憶されている輝度レベルが低	モニター前面のCONTRASTコントロール
★GAIN CONTROL ★MINIMUM LIMIT	いため,明部のホワイトバランス調整がで	で輝度を下げる。
7/(4/11/11/11/03/11	きない。	
OUT OF RANGE	プローブに記憶されている輝度レベルが高	モニター前面のBRIGHTNESSコントロー
*BIAS CONTROL *MAXIMUM LIMIT	いため、暗部のホワイトバランス調整がで	ルで輝度を上げる。
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	きない。	
OUT OF RANGE	プローブに記憶されている輝度レベルが高	モニターの前面のCONTRASTコントロー
★GAIN CONTROL ★MAXIMUM LIMIT	いため、明部のホワイトバランス調整がで	ルで輝度を上げる。
	きない。	
UNSTABLE ERROR	外光による妨害が多い。	周囲光をさえぎる。

1-10. 主な仕様

一般

形式 マイクロプロセッサー内蔵制御回路,

モニター本体内部装着型

オートセットアップ項目

ホワイトバランス (バイアス, ゲイン)

色相(クロマフェーズ),飽和度(ク

ロマゲイン)自動調整機能搭載

動作温度

0 ~40℃

保存温度

雷源

-10~+60°C

モニター本体より供給

必要外部機器

プローブBKM-2053またはBKM-2052

(オートホワイトバランス調整用)

オートクロマ/フェーズ調整機能

セットアップ誤差 クロマゲイン:1%以下

クロマフェーズ:1°以下

(入力信号により変動あり)

セットアップ時間 TYPICAL 10秒以内

入力カラーバー

「1-4-1.基準カラーバー信号」の表を参照

オートホワイトバランス調整機能(プロープ接続時)

基準白色

最大4色までメモリー可能

メモリー1 (工場出荷時に設定)

BKM - 2053 / 2052 - 01 : 6,500 °K,

40fL

BKM - 2053 / 2052 - 02 : 6,500 °K,

40fL

BKM - 2053 / 2052 - 03 : 9,300 °K

40fL

メモリー2~4:任意の色温度をメモ

リー可能

メモリー形式

基板:不揮発性メモリー (バッテリー

バックアップ, バッテリー寿命5年

以上)

プローブ:不揮発性メモリー (バック

アップバッテリー不要, メモリー保

持期間10年以上)

標準輝度(100 IRE入力時)

40fL(動作可能範囲15~59fL,

使用モニターにより制限)

繰り返し精度 色度: CIE色度点

とがありますが, ご了承ください。

色度: CIE色度点x, yより±0.002以

内の誤差

輝度:5%以下の誤差


色温度セットアップ時間

TYPICAL 30秒 (BKM-2053使用時)

TYPICAL 60秒 (BKM-2052使用時)

本機の仕様および外観は、改良のため予告なく変更するこ

1-11. 梱包



SECTION 1 OPERATION

1-1. OUTLINE

1-1-1. Outline of the Auto Set-up System

The BKM-1450 is a board kit to equip the Sony BVM-1310/1410P* color video monitor with an Auto Set-up System.

Auto chroma/phase adjustment

The chroma phase, chroma gain (color saturation), brightness, contrast and set-up level can be adjusted automatically to the standard level using a reference color bar signal. This allows easier and faster adjustment of multiple monitors if they have the Auto Set-up System.

Auto white balance adjustment

The white balance can be adjusted automatically using a reference white stored in the optional Sony BKM-2053 or BKM-2052 auto set-up probe. The probe can read three desired color temperatures from monitors and store them in memory, in addition to the factory-preset standard color temperature, 6,500°K (North America and Europe) or 9,300°K (Japan). Any of the four color temperatures can be used as reference. Once the standard white used in your broadcasting station is stored, that particular white can be obtained easily at any time (Memory life: more than 100 years).

Color temperature of multiple monitors can be adjusted with one probe.

Selection of the color temperature

Four color temperatures used as a reference white for auto white balance adjustment are stored in the memory of this adaptor. The memory is backed up and the stored color temperatures are retained even if the power is turned off. Simply by recalling from the memory, the monitor is set to the stored color temperature automatically without using the probe.

Color analyzer function (with the BKM-2053 only) The BKM-2053 probe can read white data from a certain monitor and display the percentages of red, green and blue to those of the reference white. These data are usable for adjusting the brightness and contrast of the monitor which were read as "out of the range" during auto white balance adjustment or for adjusting the white balance on monitors not equipped with the auto set-up system.

Operation menu display

The messages indicating the sequence of auto set-up operation, result of adjustment, error, etc. are displayed on the screen.

1-1-2. Parts List

This adaptor consists of the following parts.

- Circuit board block (BN, BO and BP circuit boards)
 (1)
- HE circuit board (1)
- Control panel (1)
- Connecting cable (with 8-pin connectors) (1)

Notes on the modification of the BVM-1310 monitor


To install this Auto Set-up Adaptor, some modifications are required to BVM-1310 color video monitors with the serial Nos. 0010001 to 001 0250. For details, refer to Section 2 of this manual.

The BVM-1410P does not conform to the FCC regulations of the USA.


1-2. MOUNTING

1-2-1. Mounting the Control Panel and HE Circuit Board


1 Pull out the right drawer of the monitor and remove the control panel.



2 Remove the HE circuit board.




3 Plug the connectors removed in step 2 into the HE circuit board of this kit.




Leave the black connector (removed from HE-103) free.

- 4 Secure the HE circuit board using the 4 screws removed in step 2.
- 5 Push the wires in between the board and the chasis.




6 Secure the control panel of this kit using the 4 screws removed in step 1.




1-2-2. Mounting the Circuit Board Block

- 1 Remove the top cover of the monitor. (Refer to Section 2 of this manual.)
- Pull out all the circuit boards from the B1 through BJ compartments on the right side of the monitor.




- 3 Pull out the BA circuit board halfway and pull out the 3 free connectors located at the top of the TB board and behind the BA board. Replace the BA board.
- 4 When the BKM-1440 RGB/component adaptor is not installed, pull out the 3 free connectors located at the bottom of the TB circuit board.*
- Disconnect the yellow 8-pin connector from the TB-15 terminal located on the TB board (at the back of BI slot).




When the BKM-1440 is installed, these 3 connectors have been plugged into terminals on the BF board. Leave them connected. It is not necessary to connect anything to the BP-5 terminal.


6 Plug the red 10-pin and yellow 12-pin connectors into the BO-3 and BN-2 terminals, respectively, on the circuit board block.




7 Fully insert the circuit board block into the B4 and B5 compartments by sliding it along the slots.



- 8 Plug the yellow 2-pin connector (removed in step 4) into the BP-5 terminal* and the yellow 8-pin connector (removed in step 5) into the BP-2 terminal.
- 9 Connect the BP-3 terminal and the TB-15 terminal using the supplied connecting cable.



10 Arrange the wires using the cord clamp.




11 Replace the circuit boards to the B1 through BJ compartments.

If any circuit boards were previously installed in the B4 and B5 compartments, insert them into other appropriate compartments, referring to the operation manual of the monitor.

1-3. LOCATION AND FUNCTION OF CONTROLS IN AUTO SET-UP SECTION

Control panel (inside right drawer of monitor)



RESET key

Press to reset the auto set-up operation and return to the initial status. This key is operative even when automatic adjustment is in operation.

2 ENT (enter) key

Press to advance to the next step during auto set-up operation and to present next menu choice. This key is also used to start the auto set-up operation.

3 ESC (escape) key

Press to return to the previous step during auto setup operation. This key is not operative while automatic adjustment is in operation.

◆ (cursor) key

For selecting options from menus. Each time this key is pressed, the cursor moves downwards, and then to the top.

6 * (asterisk) key

Press to set the monitor to color temperature selection mode. Also used to select the memory position of the probe in color analyzer mode.

ROBE connector

Connect the optional BKM-2053 or BKM-2052 auto set-up probe.

1-4. AUTO CHROMA/PHASE ADJUSTMENT

The chroma phase, chroma gain (color saturation), brightness, contrast and set-up level can be adjusted automatically referring to the input color bars.

1-4-1. Usable Color Bars

Color bars for auto chroma/phase adjustment differ according to the video signal (composite, RGB or component) and the color system (NTSC, PAL or SECAM).

Video alg		Usable Color page	
	NTSC	FULL FIELD: white 100%/saturation 75%/set-up 0—10% or white 75%/saturation 75%/set-up 0—10% SMPTE/SPLIT	
Composite	PAL	100 BARS: white 100%/saturation 100%	
	PAL-M	EBU BARS: white 100%/saturation 75%	
	SECAM	100 BARS: white 100%/saturation 100/75% 75 BARS: white 75%/saturation 75%	
RGB		100 BARS: white 100%/saturation 100/75% 75 BARS: white 75%/saturation 75% 5/10 STEPS: stair steps 5 or 10	
Component 4:2:2		100 BARS: white 100%/saturation 100/75% 75 BARS: white 75%/saturation 75% SMPTE/SPLIT	

1-4-2. Preparations on the Monitor

Set the switches on the monitor as follows:

Front panel

- MODE selector → <u>AUTO</u> (released)
- SCAN MODE
 (H delay) and
 (V delay) switches

 → OFF (released)
- CONTRAST, BRIGHTNESS, CHROMA and PHASE MANUAL switches — Preset position (released)

HB circuit board (inside the right drawer)


- PIC. SET UP POSITION control → Center position
- MATRIX switch → OFF

Input selection

Set the INPUT selector on the front panel and the INPUT SELECT buttons and COLOR STANDARD buttons on the HB circuit board appropriately according to the input signal*.


^{*} To display each input signal, a decoder board for the signal is required. Refer to the operation manual of the monitor.

1-4-3. Auto Chroma/Phase Adjustment



Using RGB or component signal color bars

1 Press the ENT key.



2 Select the system of the video signal by pressing the </pr



Press the ENT key.

3 Select the color bar signal to be used by pressing the ❖ key.

(For usable color bars for each video signal system and color system, see "1-4-1. Usable Color Bars".)



or

RGB BARS
■100 BARS
75 BARS
5/10 STEPS
-SELECT & PRESS ENT-




Press the ENT key.

The auto chroma/phase adjustment will be executed.

The display on the screen will be in blue only mode during adjustment.

When the adjustment is finished, the following message will be displayed (and will disappear in approximately 1 second).


Example: component



- For SECAM and component signal, the phase is not adjusted and "—" is displayed.
- For RGB signal, the phase and chroma is not adjusted and "—" is displayed.


When the adjustment is not completed

 If any of the MANUAL switches on the front panel of the monitor is depressed, the following message will appear when the ENT key is pressed in step 1.




Press to release the depressed MANUAL switch and press the ENT key again.

 If an inappropriate color bar signal has been used, an "NG" will be displayed to indicate the adjustment of the corresponding item cannot be completed.




Press the ESC key to return to the display shown in step 3. Feed the correct color bar signal (see "1-4-1. Usable Color Bars".) and press the ENT key.




1-4-4. Manual Chroma/Phase Adjustment

When this auto set-up adaptor is installed in the monitor, the auto chroma/phase adjustment is normally used for easy adjustment. However, the set-up range using the monitor front controls with the auto chroma/phase adjustment is narrower than the manual adjustment (which is to be carried out when the auto set-up adaptor is not installed). Set to the manual adjustment mode if necessary, as follows.



Note

The illustration below indicates the construction of the chroma/phase control circuit. As shown in the illustration, the PRESET controls function in either of the AUTO or MANUAL chroma/phase adjustment mode. Be careful not to adjust the PRESET controls after auto chroma/phase adjustment to keep automatic adjustment settings.



1-5. AUTO WHITE BALANCE ADJUSTMENT

Use a composite video signal for auto white balance adjustment.

Although auto white balance adjustment cannot be executed in RGB or component signal mode, the white balance adjusted with the composite video signal can be read in "SELECT MONITOR MEM" mode (see "1-5-3. Selection of the Color Temperature") when an RGB or component signal is to be displayed.

Before auto white balance adjustment

- Block out as much incident ambient light as possible.
- Adjust landing. Uniformity deviation will increase the error in adjustment.
- Demagnetize the screen using the DEGAUSS switch.

1-5-1. Memorizing the Color Temperature

The desired three color temperatures can be stored in the BKM-2053 or BKM-2052 auto set-up probe, in addition to that stored at the factory (6,500°K or 9,300°K). Auto white balance adjustment can then be carried out using one of the stored color temperatures as reference white.

Preparations

- Complete the auto chroma/phase adjustment using the reference color bars.
- Set the monitor to the color temperature and the brightness to be stored using the BIAS/GAIN ADJUST, BRIGHTNESS and CONTRAST controls.


Version of the probe

The white at the same color temperature may not be reproduced if the phosphor of the monitor does not match the version of the probe. Check the following list.

of Figure 20.		esolois emigratilite storeis essat estable essatelice estable
BKM-2052-01	SMPTE EBU	D6,500°K D6,500°K
-02 -03	EBU	D9,300°K
BKM-2053-01	SMPTE	D6,500°K
-02	EBU	D6,500°K
-03	EBU	D9,300°K


Connection of the probe

To store the color temperature of the BVM-1310/1410P



BKM-2052/2053 probe

To store the color temperature from another reference monitor (not equipped with the auto set-up system)



Reference monitor

With the connection above, the reference signal is supplied from the BVM-1310/1410P to the reference monitor. The auto set-up message will be displayed on the BVM-1310/1410P screen.

Notes on the reference monitor

- The reference monitor should have the same phosphor as that of the BVM-1310/1410P auto set-up monitor.
- When using the BKM-2052 probe, the reference monitor should have the SCREEN switches.
- The VIDEO IN connector of the reference monitor should be terminated at 75 ohms.
- When the picture brightness and contrast on the reference monitor are excessively different from those on the auto set-up monitor, the color temperature cannot be stored. Before proceeding, match the contrast and brightness on the reference monitor to those of the auto set-up monitor.

Phosphor chromaticity coordinates

BVM-1310 (SMPTE)

	X.	Υ
Red	0.630	0.340
Green	0.310	0.595
Blue	0.155	0.070


BVM-1410P (EBU)

	Х	Υ
Red	0.640	0.330
Green	0.290	0.600
Blue	0.150	0.060

Error: less than ±0.005

Operation using the BKM-2053 probe

1 Press the ENT key.




2 Make sure that the cursor is at "MEMORIZE COL. TEMP".

If it is not, move the cursor to that position by pressing the ❖ key.




If the probe is not connected to the PROBE connector correctly, the message "CONNECT PROBE" will be displayed. Connect it correctly and press the ENT key.

3 Select the desired memory position, "P-MEM1" to "P-MEM3", to which the color temperature is to be stored by pressing the ❖ key.



Press the ENT key.

4 Mount the probe on the screen of the monitor from which the color temperature is to be stored in the memory.




5	The probe will extract the color tem in its memory.	nperature data from the wh	nite on the monitor screen and store it
	•		will be displayed (and will return to the
		PROCEDURE COMPLETED!	

Note

When the color temperature cannot be stored, the "OUT OF RANGE" indication will blink on the screen. Remove the cause and make the necessary correction referring to "Error messages". (See "1-8. Error Messages.") Then press any key (except RESET) in the auto set-up section of the monitor and repeat the procedure.

Operation vising the statical probe



To store color temperature To store color temperature of reference monitor of the BVM monitors Mount the probe on the screen of the monitor from which the color temperature is to be stored. SET PROBE ON CRT ---PRESS ENT---Press the ENT key. The following message will be displayed. SET RED ONLY Set the screen switches on the reference Press the ENT key. Only the red beam will be turned on automonitor to turn on the red beam only. matically and the red data will be stored. When the red data is stored, the following message will be displayed. SET GREEN ONLY Press the ENT key. The red data will be stored. When the red data is stored, the following message will be displayed. SET GREEN ONLY

To store color temperature of the BVM monitor	To store color temperature		
7 Press the ENT key. Only the green beam will be turned on auto-	8 Set the screen switches to turn on the green beam only.		
matically and the green data will be stored. When the green data is stored, the following message will be displayed.	Press the ENT key. When the green data is stored, the following message will be displayed.		
SET BLUE OHLY	SET BLUE ONLY		
8 Press the ENT key. Only the blue beam will be turned on auto-	10 Set the screen switches to turn on the blue beam only.		
matically and the blue data will be stored. When the blue data is stored, the following message will be displayed (and will return to the menu in step 3 after approximately 1 second).	11 Press the ENT key. When the blue data is stored, the following message will be displayed (and will return to the menu in step 3 after approximately 1 second).		
PROCEDURE COMPLETED!	PROCEDURE COMPLETED!		
Now the color temperatures have been stored in the selected memory of the probe.	Now the color temperature has been stored in the selected memory of the probe.		

Note

When the color temperature cannot be stored, the "OUT OF RANGE" indication will blink on the screen.

Remove the cause and make the necessary correction referring to "1-8. Error messages". Then press any key (except RESET) in the auto set-up section of the monitor and repeat the procedure.

1-5-2. Setup This Monitor

The white balance will be adjusted automatically using any one of the color temperatures stored in the probe as reference.

For storing the color temperature, see "1-5-1. Memorizing the Color Temperature."

Preparations

- Connect the probe to the auto set-up monitor on which the white balance is to be adjusted.
- Complete the auto chroma/phase adjustment on the monitor on which the white balance is to be adjusted.
- Refer to "Before auto white balance adjustment" on page 1-11(E).

Operation

MONITOR AUTO SETUP

→■AUTO CHROMA/PHASE
SETUP THIS MONITOR
MEMORIZE COL.TEMP
ANALYZE COL.TEMP

(NTSC) ← Color system

-SELECT & PRESS ENT-

2 Make sure that the cursor is at "SET UP THIS MONITOR".

If it is not, move the cursor to that position by pressing the key.

Cursor




Press the ENT key.

If the probe is not connected to the PROBE connector correctly, the message "CONNECT PROBE" will be displayed. Connect the probe correctly and press the ENT key.

3 Select the memory position of the probe in which the desired color temperature is stored by pressing the

♣ key.



Mount the probe on the monitor screen.		
SET PROBE ON CRT		
PRESS ENT		
Press the ENT key.		
5 The screen will first become dark to calibrate the ambient light. The auto white balance adjustment will be executed. When the adjustment is finished (after about 30 seconds using the BKM-2053 or about 60 seconds using the BKM-2052), the following message will be displayed for approximately 1 second.		
PROCEDURE COMPLETED!		


Now the color temperature data stored in the probe has been transferred to the memory of the auto set-up monitor.

- To cancel on going automatic adjustment, press the RESET key. The initial menu will be displayed.
- If auto white balance adjustment cannot be completed, the "OUT OF RANGE" indication will blink on the screen. Remove the cause and make the necessary correction referring to "1-8.Error messages". Then press any key (except RESET) in the auto set-up section of the monitor and repeat the procedure.

1-5-3. Selection of the Color Temperature

When the auto white balance adjustment has been carried out in "SET UP THIS MONITOR" mode (see "1-5-2. Setup This Monitor"), the color temperature of the reference white used in the adjustment is automatically stored in the same memory position on the monitor. Once the color temperature is transferred in this way, it can be recalled without using the probe.

This section also provides a choice of manual white balance adjustment using the GAIN/BIAS ADJUST controls inside the drawer of the monitor.



Note


The memories of the color temperature in the monitor are indicated like "M-MEM1" on the display and the memories in the probe are indicated like "P-MEM1". The color temperature stored in a probe memory is stored in the monitor memory of the same memory number when automatic white balance adjustment is completed.

1-6. COLOR ANALYZER FUNCTION (with the BKM-2053 probe only)


The BKM-2053 probe reads the red, green and blue color data from a certain monitor and displays the percentages of the data read from the screen to the reference color data stored in the probe. The data display will appear on the set-up monitor screen with the luminance in footlambert (FL). This function is usable when you adjust the white balance of the monitors not equipped with the auto set-up system, or check the cause of an "out of range" error in "MEMORIZE COL. TEMP" mode and reajust the luminance level of the monitor.

Connection of the probe

To read the color data of the BVM-1310/1410P



To read the color data from a monitor not equipped with the auto set-up system



With this connection, the reference signal is supplied from the BVM-1310/1410P to the other monitor. The color data will be displayed on the BVM-1310/1410P's screen.

Operation

Press the ENT key. MONITOR AUTO SETUP ■AUTO CHROMA/PHASE SETUP THIS MONITOR MEMORIZE COL. TEMP ANALYZE COL. TEMP Color system (NTSC) ◀ -SELECT & PRESS ENT-Cursor Make sure that the cursor is at "ANALYZE COL. TEMP". If it is not, move the cursor to the position by pressing the key. Press the ENT key. If the probe is not connected to the PROBE connector correctly, the message "CONNECT PROBE" will be displayed. Connect it correctly and press the ENT key. Mount the probe on the screen of the monitor from which the color data is to be extracted. SET PROBE ON CRT ---PRESS ENT---Press the ENT key. Percentage to the reference data (%) R: red Reference data indication G: green The memory position of the probe is displayed D6)(R=000 G=000 B=000) B: blue here and the color temperature stored in that position by the "MEMORIZE COL. TEMP" mode is selected as the reference data. D6: D6500 or D9: D9300 00.0FL) HIGH M1: MEM-1 M2: MEM-2 Highlight/lowlight indication (Select with the 🕹 key.) M3: MEM-3 Luminance (fL) HIGH: highlight (100% white) LOW: lowlight (20% white) When using other reference data, press the * key. SELECT PROBE MEM ■P-D6500 (SMPTE) P-MFM1 P-MEM2 P-MEM3 -SELECT & PRESS ENT-

Select the desired memory position by pressing the 4 key and press the ENT key.

- 6 Select the highlight (HIGH) or lowlight (LOW) at which the color data is to be read. Each time the & key is pressed, the HIGH and LOW indications appear alternately.
- 7 Press the ENT key.

The color data at the selected highlight or lowlight will be read and displayed on the auto set-up monitor screen.

D6 R=100 G=100 B=100

40.5FL

HIGH


- 8 To display the data at the other light, press the ❖ key.
- To cnacel the "ANALYZE COL. TEMP" mode, press the ESC key. The display in step 1 will appear.

Note on data indications

The luminance level which the probe can read is between 0.0 and 59.0 fL at HIGH position, and 0.0 and 2.0 fL at LOW position (at D9300°K or D6500°K). If the luminance of the screen is more than 59.0 or 2.0 fL, "---" will be displayed in place of the percentage digits.

If you carry out the "MEMORIZING COL. TEMP" operation (see "1-5-1. Memorizing the Color Temperature") in this condition, the "OUT OF RANGE" indication will blink and the color temperature cannot be stored in the probe.

SECTION 2 BOARD ARRANGEMENT DIAGRAM WHEN INSERTING



CAUTION TO BE EXERCIRED WHEN INSERTING

B1 through B5 compartments accept the optional board as follows:

Board name (Function)		Compartment name				
Board name (Function)	B5	В4	В3	В2	В1	
BB (NTSC COMB)	х	0	0	0	0	
BC (NTSC DECOPER)	0	Ö	0	0	0	
BD (PAL DECODER)	0	0	0	0	0	
BE (SECAM DECODER)	0	0	0	0	0	
BM (PAL-M DECODER)	0	0	0	0	0	
BF (RGB/COMPONENT)	х	x	0	х	х	
BL (VITC)	х	х	×	0	x	


o : acceptable x : not acceptable

Notes

- Inset BA, BG, BH, BI and BJ boards into their respective compartments having the same name.
- Do not leave B5 compartment blank. Insert one of the boards specified in the above table. If no board is inserted, the luminance/chrominance or chrominance channel will not be activated in composite signal mode.
- Do not insert BD (PAL DECODER) and BM (PAL-M DECODER) boards simultaneously. This causes malfunction of the monitor.

To insert a board


Insert with the parts side facing towards the front of the monitor.



The BP board should be inserted in the B5 position, and the BN board should be inserted in the B4 position

If the B4, B5 position is vacant, be sure to always insert in the B4, B5 position.

第 2 章 挿入時の基板配置図



挿入時の注意

B1からB5は以下に示すオプション基板を使うことが できます。


甘仁夕 (掛北)		区画名			
基板名(機能)	B5	В4	В3	В2	В1
BB (NTSC COMB)	х	0	0	0	0
BC (NTSC DECODER)	0	0	0	0	0
BD (PAL DECODER)	0	0	0	0	0
BE (SECAM DECODER)	0	0	0	0	0
BM (PAL-M DECODER)	0	0	0	0	0
BF (RGB/COMPONENT)	х	x	0	х	х
BL(VITC)	х	х	х	0	×

O: 使用可 ×: 使用不可

- ・BA, BG, BH, BI, BJ 基板を同じ名称の場所に 挿入して下さい。
 ・B5は空けないで下さい。 必ず上の表で指示している基板から1基板を選んで挿入して下さい。もし、基板を挿入しないと輝度/クロミナクスチャンネル。 及びクロミナンスチャンネルは合成信号モードでは
- 働きません。
 BD (PAL DECODER) 基板とBM基板 (PALM DECODER) を同時に挿入しないで下さい。もし挿入するとモニターが故障します。

基板の挿入法


基板の部品面をモニターの前面方向に合わせて挿入し て下さい。



BP基板は、B5のポジション、BN基板は、B4のポジショ ンに収納して下さい。

もし、B4、B5のポジションが空いている時は、必ずB4、 B5のポジションに収納して下さい。

1-11. PACKING



1-36(E) (3)

1-10. SPECIFICATIONS

General

Type

Control circuit with a built-in microprocessor to be mounted

in the monitor

Auto set-up items

White balance (bias, gain), chroma phase, chroma gain

(color saturation)

Operating temperature

0 to 40°C (32 to 104°F)

Storage temperature Power requirements

 $-10 \text{ to } +60^{\circ}\text{C} \text{ (14 to } 140^{\circ}\text{F)}$ Supplied from the monitor

Optional component required

BKM-2053 or BKM-2052 auto set-up probe (for the auto white

balance adjustment)

Auto chroma/phase adjustment

Setting error

Chroma gain: Less than 1% Chroma phase: Less than 1° (Depending on the input signal)

Set-up time

Typical within 10 sec.

Input color bar signal See "1-4-1. Usable Color Bars."

Auto white balance adjustment

(with the probe connected)

Reference white

One of 4 color temperatures

stored in the probe

Memory 1 (Factory-preset) BKM-2053/2052-01: 6,500°K,

40 fL

BKM-2053/2052-02: 6,500°K,

40 fL

BKM-2053/2052-03: 9,300°K,

40 fL

Memory 2 to 4: User definable

Memory

Circuit board: Non-volatile memory (with battery backup, battery life more

than 5 years)

Probe: Non-volatile memory (no need of battery backup, memory life more than 10

years)

Standard brightness (100 IRE input)

40 fL (operable in 15 to 59 fL

range)

The maximum brightness is limited by the monitor.

Short-time repeatability

Chromaticity: Less than ± 0.002 in x and y coordinates of CIE

chromaticity

Luminance: Less than 5%

Color temperature set-up time


Typical 30 sec. (with the BKM-2053) Typical 60 sec. (with the BKM-2052)

Design and specifications subject to change without

notice.

1-7. Serviceman Mode


By pressing the RESET key and the ESC key simultaneously, the serviceman mode is selected. In this mode, there are five menus as follows.



The ''4:2:2 INSTALLATION'' menu is used only when the BKM-1450 is mounted on a monitor with digital video input connectors such as BVM-2010D/PD/PMD.

The "INITIAL LUMINANCE" menu is for selecting the luminance for the color temperature D9300K or D6500K.

1-7-1. Selecting the Luminance for D9300K or D6500K



1-8. ERROR MESSAGES

During auto chroma/phase adjustment

Display	Meaning	Correction
NG	The color bar selection is not correct. The video input is not terminated.	Select the correct color bar. Mount a terminator.
SET UP: NG	The PIC. SET UP POSITION control on the monitor is not set to the center position.	

During auto white balance adjustment


Display	Meaning	Correction
PROBE NOT CONNECTED!	The probe has not been connected to the PROBE connector correctly.	Connect the probe correctly.
OUT OF RANGE *LUMINANCE (HIGH) *TOO LOW FOR PROBE	The highlight luminance level of the reference monitor is too low for the probe to store it.	Raise the luminance level using the CONTRAST control on the reference monitor.
OUT OF RANGE *LUMINANCE (LOW) *TOO LOW FOR PROBE	The lowlight luminance level of the reference monitor is too low for the probe to store it.	Raise the luminance level using the BRIGHTNESS control on the reference monitor.
OUT OF RANGE *LUMINANCE (HIGH) *TOO HIGH FOR PROBE	The highlight luminance level of the reference monitor is too high for the probe to store it.	Lower the luminance level using the CONTRAST control on the reference monitor.
OUT OF RANGE *LUMINANCE (LOW) *TOO HIGH FOR PROBE	The lowlight luminance level of the reference monitor is too high for the probe to store it.	Lower the luminance level using the BRIGHTNESS control on the reference monitor.
OUT OF RANGE *BIAS CONTROL *MINIMUM LIMIT	The luminance level stored in the probe is too low for the white balance at lowlight to be adjusted.	Lower the luminance level using the BRIGHTNESS control on the front of the monitor.
OUT OF RANGE *GAIN CONTROL *MINIMUM LIMIT	The luminance level stored in the probe is too low for the white balance at highlight to be adjusted.	Lower the luminance level using the CONTRAST control on the front of the monitor.
OUT OF RANGE *BIAS CONTROL *MAXIMUM LIMIT	The luminance level stored in the probe is too high for the white balance at lowlight to be adjusted.	Raise the luminance level using the BRIGHTNESS control on the front of the monitor.
OUT OF RANGE *GAIN CONTROL *MAXIMUM LIMIT	The luminance level stored in the probe is too high for the white balance at highlight to be adjusted.	Raise the luminance level using the CONTRAST control on the front of the monitor.
UNSTABLE ERROR	The flicker of the ambient light affects the probe.	Block out the ambient light.

1-9. オートセットアップフローチャート


1-9-1. オートセットアップ


コンポジット信号の場合


次のメニュー に進む場合: ENTキーを押す。 前のメニュー に戻る場合: ESCキーを押す。 メニューを選択する場合: ◆ キーを押す。 動作を中断する場合: RESETキーを押す。












1-9-2. サービスマンモード




* D/AコンバーターとプローブBKM-2053の調整用のメニューです。 詳しくは第2章以降をご覧ください。 ** 本機をデジタル入力つきのモニターに取り付けた場合のみ使用します。


1-9. Auto Set-up Flowchart


1-9-1. Auto Set-up

In case of composite mode


To advance to the next step, press ENT.
To return to the previous step, press ESC.
To select the menu, press $\sqrt[4]{}$ To cancel the operation, press RESET.








monitor.



1-9-2. Serviceman Mode



^{*} These menus are for adjustment of the D/A converter inside the monitor or of the BKM-2053 probe.

^{**} This menu is used only when the BKM-1450 is mounted on a monitor with digital video input connectors.

SECTION 3 INSTALLATION

3-1. INSTRUCTIONS

MODIFICATIONS

Following modifications should be required when BKM-1450 is being installed in BVM-1310.


Modifications

1. BVM-1310 Serial No. 10,001 to 10,060

TB board

- 1) Additional wire should be soldered from A16 (B2 slot) to A16 (B5 slot).
- 2) Additional wire should be soldered from A18 (B2 slot) to A16 (B4 slot).

TB Board




2. Serial No. 10,001 to 10,250

BI board

- 1) Cut pattern on soldering side and solder additional wire.
- 2) See below.

BI Board



第3章 基板の取り付け

BVM-1410に BKM-1450を取り付ける場合は特に修正変 更の必要はありません。

第 4 章

回路説明

4-1. 動作原理


4-1-1. AUTO chroma/phase

モニターTVの調整に用いられるカラーバー信号を、正確 に復調した後のブルー信号波形は図4-1のようになります。



図4-1

つまりシアン,マゼンタ,青の各レベルが同一となります。 このことを利用してAUTO chroma/phaseでは、シアン、 マゼンタ、青の各電圧をマイクロコンピューターにより測 定比較して, 同一電圧になるように各制御電圧の調整を自 動的に行います。又NTSC信号では、約0~10%のSet up が付加されており、その分ペディスタルレベルにより上がっ ています。このセットアップレベルとビデオのクランプレ ベルが一致していないと、CONTRASTの変化により黒レ ベルは動いてしまい, 黒浮き, 黒沈みといった形で画像に 影響を与えます。



BVM-1410モニターでは、PICTURE SET UP機能で、 ビデオ回路のクランプレベルを入信号のセットアップレベ ル (設定したレベル) に肉眼で容易に合わせることができ

Auto chroma/phaseモードでは、このPICTURE SET UP機能を使ってCPUは、クランプレベルをセットアップ レベル(設定したレベル)に自動的に合致するように調整 する。(Auto chroma/phase モードが実行されるとモニ ターは、PICTURE SET UP機能によって瞬間的に狭い 映像を表示する。)

4-1-2. AUTO WHITE BALANCE

1. SET UP THIS MONITOR


CRTの光を光センサープローブ (BKM-2052 or BKM-2053) によって電気信号に変換してBKM-1450に送り ます。この電圧をデジタルに変換した後、基準データ ーと比較して、等しくなるようにBVM-1410本体の調 整を自動的に行います。約20 IRE の白信号でBias 調 整を行い、100 IREの白信号で Gain 調整を行います。

2. MEMORIZE COL TEMP


CRTの光を光センサープローブによって電気信号に変 換した後、BKM-1450内で、デジタル変換し、プロー ブ内の不輝発性デジタルメモリーに書き込みます。こ のデーターはSET UP THIS MONITORモードで基準 データーとして使われます。Biasデーターは約20IRE Gainデータは約100IREの白信号の輝度を使用します。 この白信号は、BKM-1410の後部パネルG outより出 力されますので、任意のモニターのWHITE BALAN-CEを記憶することができます。

4-1-3。 CPU基板 (BN基板)

CPUは常時VパルスによってNMI割り込みがかけられ図4 3のプログラムを実行した後、次の割り込みがくるまで停 止します。NMIルーチン内では、RAMよりデータ読み出し、 それをD/Aコンバーターに送りアナログ電圧に直した後 サンプルホールドして各種の制御電圧にしています。 さらにこの中でKEYサーチを行っておりKEYが押される とそれに相当するプログラムが起動されます。



INT割り込みは、サンプルホールドパルスゼネレーターよ り発生するパルスによってかかる。この割り込みが発生す るとS/H(1)の出力電圧をD/Aの出力と比較してデジ タル値に変換する。



- **PHASE** BRIGHT
- SET UP
- WINDOW LEVEL
- CHROMA
- CONTRAST
- RED BIAS
- RED GAIN
- GREEN BIAS
- 10. GREEN GAIN
- 11. BLUE BIAS 12. BLUE GAIN

4-1-4. PULSE GEN及びD/A CONVERTER (Bo基板)

S/H pulse Genはビデオ信号の1フィールドにアドレス を割り付けCPUより書き込まれたのと同じアドレスにパル スを発生させる回路である。

このパルスはBP基板のS/H(1)のサンプルホールドパル スになる。これによってCPUは1フィールド内の任意の場 所をサンプルホールドし、デジタル値に変換することが出 来る。




図4-5 S/H Pulse Gen

Е

S

D/A converterには12bitを使用し、上位8bitと下位4bit に別けてラッチに書き込む。

0000 H = -9 V

FFF0H=+9Vになるように調整されている。





図4-6 D/A CONVERTER

1. Window Pulse Gen WHITE BALANCE測定の為の全白信号を作る為のパ ルスを発生する。

SYSTEMによる走査線数の切替はCPUによりコントロー ルされる。



INT割り込みは、サンプルホールドパルスゼネレーターよ り発生するパルスによってかかる。この割り込みが発生す るとS/H(1)の出力電圧をD/Aの出力と比較してデジ タル値に変換する。




図4-4

- 1. PHASE BRIGHT
- SET UP
- WINDOW LEVEL CHROMA CONTRAST
- 7. RED BIAS RED GAIN
- GREEN BIAS 10. GREEN GAIN
- 11. BLUE BIAS 12. BLUE GAIN

4-1-4. PULSE GEN及びD/A CONVERTER (Bo基板)

S/H pulse Genはビデオ信号の1フィールドにアドレス を割り付けCPUより書き込まれたのと同じアドレスにパル スを発生させる回路である。

このパルスはBP基板のS/H(1)のサンプルホールドパル スになる。これによってCPUは1フィールド内の任意の場 所をサンプルホールドし、デジタル値に変換することが出 来る。




図4-5 S/H Pulse Gen

D/A converterには12bitを使用し、上位8bitと下位4bit に別けてラッチに書き込む。

0000 H = -9V

ルされる。

FFF0H=+9Vになるように調整されている。




図4-6 D/A CONVERTER

1. Window Pulse Gen WHITE BALANCE測定の為の全白信号を作る為のパ ルスを発生する。 SYSTEMによる走査線数の切替はCPUによりコントロー

4-1-5. SAMPLE HOLD & WINDOW GEN (BP基板)

•S/H(2)

Bo基板でアナログ変換されたデータは、それぞれ該当 するサンプルホールドにより制御電圧に変換される。






図4-7



•S/H(1)


Probe又はブルー信号(BI)をBo基板で作られた pulse に よりS/HしcomparatorでD/A出力と比較してその結果 をCPUへ送る。CPUはこの比較出力を基にして、S/H された信号を12bitのデジタルデーターに変換する。 S/HパルスはCPUへのINT割り込みパルスとして使用さ れており、これによりA/D変換プログラムが起動され る。





• Window Gen


Window Pulse (from Bo基板)とCOMPO SYNC, CONPO videoよりBurstの付いた全白信号を作る。白 のレベルはD/A出力を変化させることによりCPUから 自由に調整できる。


尚この信号はG OUTコネクターより75Ωインピーダン スで出力されます。



















BO-1 GVS

B0-2 DA-1

B0-2 DA-2





SECTION 4 CIRCUIT DESCRIPTIONS

4.1. THEORY OF OPERATION

4-1-1. AUTO CHROMA/PHASE

The Waveform of blue signal which is precisely decoded from color bar signal used for the picture monitor adjustment is shown in Fig. 4-1.

As Fig. 4-1 shows, level of waveform in cyan, magenta and blue are equal.




Fig. 4-1

This principle is used in the Auto Chroma/phase mode. Measuring and comparing the voltage level of cyan magenta and blue with CPU, control voltages for chroma and phase are adjusted automatically so that the level of these 3 colors may match. In NTSC system set up level (7.5%, actually 0 to 10%) is specified as a black level, just higher level than pedestal level. See Fig. 4-4. If set up level of the incoming signal and clamp level of the video circuit in the monitor are not equal, black level of the monitor (on the picture screen) may change by contrast control. This may affect the black level of the picture.




Fig. 4-2

In BVM1310/1410P monitor, PICTURE SET UP function makes it easy to match the clamp level of the video circuit to the set up level of incoming signal by eye.

In Auto chroma/phase mode, by using this PICTURE SET UP function, CPU adjusts clamp level to match to the set up level automatically. (When Auto chroma/phase mode is executed, the monitor momentarily displays the narrow picture because PICTURE SET UP function is working.)

4-1-2. AUTO WHITE BALANCE

1. SET UP THIS MONITOR

The light output of the CRT screen is detected and converted from photo diode current to the voltage signal by the photo sensor probe (BKM2052/2053). This signal is fed to the CPU (BKM-1450) located in the monitor and is converted to digital form by A/D converter. This digital signal is compared with the reference data stored in the probe. Bias and Gain adjustment is made so that the data taken by the probe and data stored in the probe may match automatically by CPU in BVM1310/1410P. This is Auto white balance adjustment. In this procedure, bias adjustment is performed at 20 IRE signal and gain at 100 IRE signal which are generated in BKM-1450.

2. MEMORIZE COL. TEMP

The light output of CRT screen is detected by the photo sensor probe (BKM-2052/2053). The signal is fed to the CPU (BKM-1450) and is converted to digital form by A/D converter in the same way as SET UP MONITOR mode as described before. This digital signal is feed back to the probe as a data and is stored in the non-volatile memory in the probe. This stored data is used as a reference data, when SET UP MONITOR mode is executed. In this mode, 20 IRE gray signal is used as reference for Low Light and 100 IRE white signal for High Light. Luminance at 20 IRE is stored in the memory as a data for bias adjustment and at 100 IRE for gain adjustment when SET UP THIS MON-ITOR mode is executed. These 20 IRE and 100 IRE signal is generated in the CPU board (BKM-1450) and is output to G output connector at the rear panel of the monitor. This G output signal is supplied by coaxial cable to another monitor as a reference when taking color temperature into the probe from another monitor.

4-1-3. CPU BOARD (BN BOARD)

The CPU is always made NMI interruption by Vertical rate pulse and after executing Program as shown in Fig. 4-3 stops working until the next interruption is made. In the NMI routine, datas is read out from RAM and is converted to analog voltage by D/A converter. This analog voltage is used for various control voltage after it is made S/H.

In this routine key search is executed. When any key is pushed, corresponding program is made starting.




Fig. 4-3

INT interruption is made by the pulse of S/H pulse generator. When INT interruption is made, output voltage of S/H (1) is compared with the output of D/A converter and is converted to digital value.




Fig. 4-4

1. PHASE 2.

BRIGHT SET UP

WINDOW LEVEL 4. CHROMA

CONTRAST

RED BIAS

RED GAIN GREEN BIAS


GREEN GAIN 10. 11. BLUE BIAS

12. BLUE GAIN

4-1-4. PULSE GEN AND D/A CONVERTER (Bo BOARD)

The S/H (Sample and Hold) pulse generator generates a pulse in the same address in a vertical field address is allocated by CPU.


This pulse is used as a S/H pulse for S/H (1) circuit on BP board. By this pulse CPU can make S/H at the desired position in a field.



S/H Pulse Gen

D/A converter has 12 bits. 12 bits are divided to upper 8 bits and Lower 4 bits.

In this system, adjustment is made that 000H = -9V and FFF0H = +9V.



D/A CONVERTER

1. Window pulse generator

This generator generates a pulse used to generate white signal which is 20 IRE and 100 IRE.

Selection of scanning system (50/625 or 60/525) of the white signal is made by CPU.

and con-

signal by

nal is fed d is con-

tal signal

e probe. taken by

ch auto-

to white tment is E signal




Fig. 4-3

INT interruption is made by the pulse of S/H pulse generator. When INT interruption is made, output voltage of S/H (1) is compared with the output of D/A converter and is converted to digital value.




Fig. 4-4

 1. PHASE
 7. RED BIAS

 2. BRIGHT
 8. RED GAIN

 3. SET UP
 9. GREEN BIAS

 4. WINDOW LEVEL
 10. GREEN GAIN

 5. CHROMA
 11. BLUE BIAS

12. BLUE GAIN

CONTRAST

4-1-4. PULSE GEN AND D/A CONVERTER (Bo BOARD)

The S/H (Sample and Hold) pulse generator generates a pulse in the same address in a vertical field address is allocated by CPU.

This pulse is used as a S/H pulse for S/H (1) circuit on BP board. By this pulse CPU can make S/H at the desired position in a field.




Fig. 4-5 S/H Pulse Gen

D/A converter has 12 bits. 12 bits are divided to upper 8 bits and Lower 4 bits.

In this system, adjustment is made that 000H = -9V and FFFOH = +9V.




Fig. 4-6 D/A CONVERTER

1. Window pulse generator

This generator generates a pulse used to generate white signal which is 20 IRE and 100 IRE.

Selection of scanning system (50/625 or 60/525) of the white signal is made by CPU.

4-1-5. SAMPLE HOLD AND WINDOW GEN (Bp BOARD)

• S/H (2)

The data which was converted to analog at the Bo board, are converted to control voltages by the corresponding S/H (Sample and Hold) circuit.






Fig. 4-7



• S/H (1)

The data taken by probe or blue signal is made S/H by S/H pulse generated in Bo board. By comparator it is compared with the ouput signal of D/A converter by which stored data in RAM is converted from digital to analog CPU converts the data made S/H to digital data which has 12 bits based on the output of comparator.

The S/H pulse is also used for INT interruption, which starts the A/D conversion program.



Window gen

White signal is generated from window pulse (Bo board), composite sync and composite video signal. The level of white signal can be controlled by CPU which controls D/A converter. This white signal is used for reference in Auto white balance and is output to G output connector at the rear panel with 75Ω impedance.




Fig. 4-9









Fig. 4-10













evs

WIND.P





第5章 調整方法

5-1. 準備

次のページ以降の基板調整方法で特に指定のない場合, SWのセッティング,接続方法は次のとおりとする。

5-1-1. SWのセッティング

フロントパネル(右)

1.	INPUT selector A	
2.	SYNC selector INT	HC 基 板
3.	MODE selector AUTO	
4.	CONTRAST MANUAL SW PRESET	7
	BRIGHTNESS MANUAL SW. PRESET	I HD 基 板
6.	CHROMA MANUAL SW PRESET	
7.	PHASE MANUAL SW PRESET	

フロントパネル(左)

8.	SCAN	MODE	SW
----	------	------	----


	UNDER SCANNOR	7
	■ H.DELAYNOR	
	■ V.DELAYNOR	
9.	SCREEN SW (R)NOR	
10.	SCREEN SW (G)NOR	HA基板
11.	SCREEN SW (B)NOR	
1 2.	APT SWNOR	
13.	BLUE ONLY SWNOR	
14.	COMB/TRAP filter selectorTRAP	


サブコントロールパネル


1 5.	INPUT SELECT buttonsB	1
1 6.	COLOR STANDARD buttons NTSC	
17.	FILTER SW OFF	
18.	MATRIX SWOFF	
19.	PAL/SECAM mode selectorD (L)	
20.	WHITE/OPERATE/SET H	IB基板
	UP selectorOPERATE	
		į .

20.	WILLEY OF EIGHTEY DET		IID as W
	UP selector	OPERATE	
21.	SPLIT SCREEN SW	OFF	
22.	CROSS HATCH SW	OFF	
23.	VITC SW	OFF	
24.	PIC . SET UP SW	OFF .	
25.	AFC SW	.2msec	DA基板


BKM-1450 26. SW1…… 右側へ倒す BP基板









フロントパネル (左)




B __ ON

NTSC ____ON





5-1-2. 接続方法



5-2. 調整方法


1. キャラクター表示位置調整


"ENT キー"を押してメニューを表示させ、上部タイトル (MONITOR AUTO SET UP) が画面のほぼ中央にくるようにBN基板のRV1を調整する。




2. サンプルホールド位置調整

調整用モニターには、ステアステップ信号が表示されているがこの信号の中のカーソル(白い線)が右から2番目のステップ(カラーバーではBLUEの位置)にくるようにBO基板RV1を調整する。











3. BLUE LEVELの調整

1. "SEL" キーを押してメニューを出しMANUALを選択する。













- 2. オシロスコープをBH基板のTP301に接続する。
- 3. 黒レベルから白レベルまでの電位差が0.7Vであることを確認する。(ずれている場合はCONT Preset volume にて調整する。)



4. オシロスコープをBP基板のTP2に接続し、黒レベルから白レベルまでの電位差が6VになるようにBP基板のRV2を調整する。







4. D/Aコンバーター調整

- 1. "ESC キー"を押したまま"RESET キー"を押す。
- 2. SET D-A CONVERTERを選んで"ENT キー"を 押す。
- 3. BP基板TP4 (アース) TP3 (+) 間にデジタルマル チメーターを接続し、電圧値が9.0±0.02Vなるよう にBO基板のRV3を調整する。

* AUTO SETUP ADJ PGM *

■SET D-A CONVERTER BKM-2053 ADJ BKM-2053 INITIALIZE 4:2:2 INSTALLATION INITIAL LUMINANCE

-FOR SERVICEMAN USE-

5. Window pulse幅調整

 プローブを接続し、(BKM-2053 プローブ) "MAIN MENU" で "MEMORIZE COLOR TEMP" を選ん で "ENT キー"を押す。

"ENT +-" "ON"

* MONITOR AUTO SETUP *

AUTO CHROMA/PHASE SETUP THIS MONITOR MEMORIZE COL.TEMP ANALYZE COL.TEMP

(NTSC) -SELECT & PRESS ENT-




"ENT +-" "ON"


* MEMORIZE COL.TEMP *


P-MEM1 P-MEM2 P-MEM3

-SELECT & PRESS ENT-

2. オシロスコープをBP基板のTP1に接続し、図5-1になるようにBO基板のRV2を調整する。












6. 出力レベル調整


(この調整はBF基板がマウントされていない時のみ)




- 1. BP基板のSW1をカードエッジ側に倒す。
- 2. Ach out と G. out をターミネーターを介して差動アンプユニット7A13に入力する。
- 3. オシロスコープをBP基板のTP1に接続しレンジを50 mV/ divにして波形が平らになるようにBP基板のRV1を回す。












SECTION 5 ADJUSTMENTS



5-1-2. CONNECTION







5-2. ADJUSTMENTS

1. ADJUSTMENT OF CHARACTER DISPLAY POSITION 3. ADJUSTMENT OF BLUE LEVEL

Press ENT KEY to display the menu, and adjust RV1 on BN board to that the top title "MONITOR AUTO SET UP" comes to the center of the picture.



1. Press SEL key to get the menu and select MANUAL.





"LCURSOR KEY" "ON"

* SELECT MONITOR MEM *

-SELECT & PRESS ENT-


M-D9300 (EBU)

M-MEM1 M-MEM2

M-MEM3

2. ADJUSTMENT OF SAMPLE HOLD POSITION

A staircase signal is displayed on the adjustment monitor. Adjust RV1 on Bo board so that the cursor (white line) in this signal is at the second step from the right (blue on color bar).





- 2. Connect an oscilloscope to BH board TP301.
- 3. Confirm that the voltage level difference between black and white levels is 0.7V.


(If not, adjust with CONT Preset Volume.)




Connect oscilloscope to BP board TP2 and adjustment BP board RV2 so that the voltage difference between black and white levels becomes 6V.









4. ADJUSTMENT OF D/A CONVERTER

- Press "RESET KEY" while pressing "ESC KEY".
- 2. Press "ENT key" to get the menu SET D-A CON-VERTER.
- 3. Connect a digital multimeter between TP4 on BP board (ground) and TP3 (+) and adjust RV3 on BO board so that the voltage value is 9.0±0.02V.

"ESC KEY" "RESET KEY" * AUTO SETUP ADJ PGM * ■SET D-A CONVERTER BKM-2053 ADJ BKM-2053 INITIALIZE 4:2:2 INSTALLATION INITIAL LUMINANCE -FOR SERVICEMAN USE-

5. ADJUSTMENT OF WINDOW PULSE WIDTH

1. Connect the probe (BKM-2053), and select "MEMO-RISE COLOR TEMP" in "MAIN MENU" to press "ENT" key.

"ENT KEY" "ON"

* MONITOR AUTO SETUP *

AUTO CHROMA/PHASE SETUP THIS MONITOR ■ MEMORIZE COL.TEMP ANALYZE COL.TEMP

(NTSC) -SELECT & PRESS ENT-



"ENT KEY" "ON"

* MEMORIZE COL.TEMP*

P-MEM1 P-MEM2 P-MEM3

-SELECT & PRESS ENT-

 Connect an oscilloscope to TP1 on BP board and adjust RV2 on BO board for the conditions shown in Fig. 5-1.







Fig. 5-1.









5-5(E)

6. ADJUSTMENT OF OUTPUT LEVEL

(This adjustment is done only when BF board is not mounted.)



- Bring down the SW1 on the BP board to the card adge side.
- 2. Input Ach output signal and G output signal to the differential amplifier unit 7A13 via a terminator.
- 3. Connect an oscilloscope to TP1 on BP board set range to 10mV/div and adjust RV1 on BP board so that the waveform is flat.



SECTION 6 DIAGRAMS

6-1. 半導体外形図

6-1. SEMICONDUCTORS

CX20197 TLP552 TL062 CP TL082 CP TL7705 CP-B μPC1060 C μPC398 C μPC4082 C	HD74HC245P HD74HC374P MC74HC374N TC74HC245P TC74HC374P TC74HC688P μPC648C	2 SA1175 2 SC2785
8 7 6 5 1 2 3 4 (Top view)	20 18 16 14 12 19 17 15 13 11 10 10 10 10 10 10 1 2 3 4 5 6 7 8 9 10 (Top view)	
HD74HC00P HD74HC02P HD74HC04P HD74HC10P	HM6264LP-12 MBM27C256-25 TC5565PL-12	2SA933S 2SC1740
MC74HC00 N MC74HC02 N MC74HC10 N SN74ALS05 AN TC74HC00 P TC74HC02 P TC74HC04 P TC74HC10 P	28 ADDRESS ADD	
1413121110 9 8	LH5080L LH5081L	2 SK381
1 2 3 4 5 6 7 (Top view)	40 135 100 20 21	S S
HD74HC123P HD74HC4040P TC4053BP TC74HC123P TC74HC147P TC74HC4040P μPD5201C	MB88303	1 SS119 1 SS133 T 1 SS148
16151413171110 9	22	cathode
HD74HC154P	2SA1048 2SA1115 2SC2458 2SC2603 DTA143XS DTC143XS	1 SS99 1 SS99-1 RD5.6 ESB2
24 13 13 13 13 13 15 15 15 15 15 15 15 15 15 15 15 15 15	E C B	cathode

6-2. 回路図, プリント図

- ・ケミコンを除くコンデンサーで耐圧50V以下のものは、 その耐圧を省略。単位はすべてμF(pはpF)
- ・抵抗で指示のないものは1/6W。単位はすべて Ω 。
- ・抵抗で指示のないものはすべて許容範囲±5%。
- ・半固定抵抗及び可変抵抗器の特性カーブ(B)は省略。
- · ____」は調整名称。
- ・----はB+ ライン。
- ·---はB-ライン。
- ・波形はカラーバー信号を入力したときの参考値。 (空端子には75Ωターミネーターを接続。)

FULL FIELD
WHITE REF 100%
AMPL 75%
SET UP 7.5
(ジェネレーター: テクトロニクス1410)

- ・使用テスターはデジタルマルチメーター (10 $M\Omega$)。
- ・丸数字は波形表の番号。

6-2. MOUNTING AND SCHEMATIC DIAGRAMS

- All capacitors are in μF unless otherwise noted. p: μμF 50WV or less are not indicated except for electrolytics.
- All resistors are in ohms, 1/6W unless otherwise noted. $k\Omega$ = 1000 Ω , $M\Omega$ = 1000 $k\Omega$
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- _____ : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Voltage veriations may be noted due to normal production tolerances.
- \bullet Reading are taken with a $10M\Omega$ digital multimeter.
- \bullet Readings and waveforms are taken with a color-bar signal input and with a 75Ω terminator connected to an open terminal.


FULL FIELD
WHITE REF 100%
AMPL 75%
SET UP 7.5

(Generator: TEKTRONX1410)

• Circled numbers are waveform references.

- — : B+ bus.
- ---: B- bus.


IC	16 17	15 7		8	l 2	5	6	3 4		9 11		0 2	18 13 14
Q				1		8 9 IO		6 5 4	3 2		7		
D	 2 2 2	8	2 3 4	22	İ			16 15 14		24 6 5			
ADJ													1




		Capit
IC 1	LH5080L	CPU
2	LH5081L	PIO
3	MBM27C256	
4	HM6264LP	RAM
5	TC74HC00P	MEM DEC
6	TC74HC123P	PULSE GEN
7	TC74HC154P	IO DEC
8	TL7705CP-B	RESET
9	TC74HC04P	INVERTER
10	TC74HC00P	GATE
11	TC74HC374P	SCREEN SW
12	TC74HC374P	FUNCTION SW
13	TC74HC374P	CG LATCH
14	MB88303	C. G
15	TC74HC147P	KEY DEC
16	TC74HC245P	PR BUFF
17	TC74HC245P	BUSS BUFF
18	SN74LS06	SW
Q 1	2SA1175	RESET
2	DTC143XS	CG DUT
3	DTC143XS	VOB OUT
4	DTA143XS	S. S. S
5	DTA143XS	S. S. P
6	DTA143XS	S. S. N
7	DTA143XS	KILLER
8	DTA143XS	RSS
9	DTA143XS	GSS
10	DTA143XS	BSS
D 1	188119	RESET-1
2	188119	RESET-2
3	188119	RESET-3
4	188119	RESET-4
5	18899	BATT REG-1
6	1SS119	BATT REG-2
14	1SS119	S. S. S
15	1SS119	S. S. P
16	188119	S. S. N
17	RD5.6ESB2	IO PROTECT-1
18	RD5.6ESB2	IO PROTECT-2
19	RD5.6ESB2	10 PROTECT-3
20	RD5.6ESB2	IO PROTECT-4
21	RD5.6ESB2	IO PROTECT-5
22	RD5.6ESB2	10 PROTECT-6
23	RD5.6ESB2	IO PROTECT-7
24	188119	

• Conductor side pattern

• Component side pattern




1 C	I	11 13 6 15	8 12	7	5 2	6 4	9 3	14 10
D								
ADJ	2	1	2					3



IC 1	TC74HC374P	H LATCH
2	TC74HC374P	V LATCH
3	TC74HC374P	M LATCH
4	TC74HC374P	L LATCH
- 5	TC74HC688P	H COMP
6	TC74HC688P	V COMP
7	TC74HC4040P	H COUNT
8	TC74HC4040P	V COUNT
9	#PC648C	DA CONV
10	#PC1060C	REF REG
1.1	TC74HC10P	OSC
12	TC74HC00P	GATE -1
13	TC74HC02P	GATE -2
14	TL082	LV CONV
15	TC74HC123P	PULSE GEN 1
16	TC74HC123P	PULSE GEN 2
D 1	188119	GATE -1
2	188119	GATE -2


: Conductor side pattern: Component side pattern

BO board (PULSE GNE, D/A CONVERTER)




BP board (SAMPLE HOLD WINDOW GEN)


I C	4 ! 2	3	20 22 19	21 18 17	15 16 12	9 10 11 13	5 23 14	6 7 8
Q	6 7 I 2 13	12 II 8 5 3 4 9				4		
D		3 2		4 6	5 7			
TP ADJ		RVI TPI,TP3,TP2	TP4 RV2					




I C	1	TC4053BP	Y SW	IC:	23	TC74HC00P	GATE -1
	2	TL082CP	CLAMP	Q	1	2SA1175	Y BUFF
	3	CX20197	VIDEO AMP 1		2	2SK381	Y CLAMP
	4	TC4053BP	WIND GEN		3	2SC3068	BUFF -1
	5	TC74HC154P	S/H GEN		4	2SC2785	BUFF -2
	6	#PD5201C	S/H -1		5	2SC2785	BUFF -3
	7	µPD5201C	S∕H -2		6	2SC2785	BUFF -4
	8	µPD5201C	S/H -3		7	2SK381	U CLAMP
	9	TL082CP	S/H BUFF -1		8	2SC2785	BUFF -5
	10	TL082CP	S/H BUFF -2		9	2SK381	W CLAMP
	11	TL082CP	S/H BUFF -3		10	2SC2785	BUFF -6
	12	TL082CP	S/H BUFF -4		11	2SC2785	BUFF -7
	13	TL082CP	S/H BUFF -5		12	2SA1175	BUFF -8
	14	TL082CP	S/H BUFF -6		13	DTC143XS	Y CLR BUFF
	15	#PD5201C	SW -1		14	DTA143XS	CLR OFF
	16	₽PD5201C	SW -2	D	1	ISS119	Y BUFF
	17	₽PD5201C	SW -3		2	ISS119	PROTECT -1
	18	#PD5201C	SW -4		3	ISS119	PROTECT -2
	19	#PD5201C	SW -5		4	ISS119	COMP
	20	#PD398C	INPUT S/H		5	ISS119	PROTECT -3
	21	TL082CP	PR BUFF		6	ISS119	PROTECT -4
	22	TL082CP	VIDEO AMP 2		7	ISS119	CLR OFF



1.6Vp-p(H)




(2) 4.8Vp-p(H)




3 6.8Vp-p(V)


• Conductor side pattern

• Component side pattern



HE board (CAL SW)






第7章 梱包図

【使用上の注意】

- 組立部品の構成部品は備考欄に照合番号で示します。
- -××, -×は標準化部品のため、セットに付いている 部品と異なる場合があります。
- * 印の部品は常備在庫しておりません。



이 또 좋은	部品コード	部	20	名

1 *1-558-919-11 א"ר עלידער (1.25 PITCH) 2 2-112-739-01 O AND M ארביביע 3 *2-112-740-01 ליותל כ"ור

部品名 備考 価格 図面番号 部品コード

> *2-112-756-01 コバカートン *2-112-754-01 クジョン(A) *2-112-754-01 クジョン(B) *2-112-755-01 クジョン(C) 4 5 6 7 Q

備考 価格

第8章

電気部品表

【使用上の注意】

┌お願い ── リファレンス番号で部品を指定するときは基板 名又はブロックを併せて指定して下さい。

- コンデンサーの単位でMFはμFを、PFはμμFを示します。 抵抗の単位Ωは省略してあります。 マイクロインダクターの単位で,MMHはmHを,UHはμHを示します。
 - 備考欄のFは不燃性抵抗を示します。
- ●-XX,-Xは標準化部品のため、セットに付いている部品と異なる場合が あります。
- * 印の部品は常備在庫しておりません。
- ●キ ン ピ:金属被膜抵抗。 サンキン:酸化金属被膜抵抗。

図面	番号	部品コード	部品名			備考	価格	図面番号	部品コード	部品名				備考	<u>価格</u>
		*A-1135-418-A	マウントス た BI					D20 D21 D22	8-71 9-1 09-89	9"17-1" RD5.6 9"17-1" RD5.6 9"17-1" RD5.6	ES-B2				
		*1 -528-166-11 *1 -563-017-11 *1 -564-460-41	F.P.C 37	リチウム テ [™] ンチ(ぐ ゴネ <i>ワ</i> ター 30P プ [®] ラク [™] (2.5MM		2P	K E	D23 D24	8-71 9-1 09-89	タ"イオート" RD5.6 タ"イオート" I SSI I	ES - B2				A
		*2-378-216-01 *4-353-708-00		a			Α		<u>1C</u>						
			יייי - מכוי: בינר":				^	101	8-759-925-44 1 -526-662-21	וC אלילו (DP 3	ウ) 40P;	I C1			L H
	C1 C2	1 -1 24-255-00 1 -1 36-1 53-00		1 MF 0.01 MF	20% 5%	50V 50V	A A	102	8-759-925-45 1-526-662-21	IC LH5081 L IC ソケット (DP 3	ウ) 40P:	102			Н
	C 3	1 -1 24-249-00	テ"ンカイ	0.1 MF	20%	50V	Α	1C3	8-759-746-63 1-526-659-00	IC MBM27C256- IC ソケット (DP 3	25				P K
	C4 C5 C6	1 -1 24-249-00 1 -1 02-863-00 1 -1 02-676-00	デ゙ンカイ セラミツ <i>ク</i> セラミツ <i>ク</i>	0.1 MF 82PF 68PF	20% 5% 5%	50V 50V 50V	A A A	104	1-526-659-00	IC HM6264P-12 IC ソケット (DP 3		IC4			VB K
	C7 C8	1 -110-195-00 1-110-199-00	マイラ ー マイラ ー	0.001 MF 0.002 ZMF	5% 5%	50V 50V	A A	1C5 1C6	8-759-202-11 8-759-202-86	IC TC74HC00P					D H
	C9	1 -1 36-1 65-00	フィッム テ ^ペ ンカイ	0.1MF	5% 20%	50V	A	IC7 IC8	8-759-202-94 8-759-908-35	IC TC74HC1 54P IC TL77050P-B					G F
	C10 C11 C12	1 -1 24-255-00 1 -1 24-255-00 1 -1 24-255-00	テーシカイテーシカイ	1MF 1MF 1MF	20% 20% 20%	50V 50V 50V	A A	1C9 1C10 1C11	8-759-202-74 8-759-202-11 8-759-203-36	IC TC74HC04P IC TC74HC00P IC TC74HC374P		•			D D J
	C1 3 C1 4 C1 5	1 -1 02-887-00 1 -1 24-255-00 1 -1 61 -039-00	セジミツ <i>ク</i> テ [™] ンカイ セジミツク	47PF 1MF 0.001MF	5% 20% 1 0%	50V 50V 25V	A A A	1C1 2 1C1 3	8-759-203-36 8-759-203-36	IC TC74HC374P IC TC74HC374P					J
	C1 6	1 -1 02-973-00 1 -1 24-236-00	セラミツク テ ^N ンカイ	1 00PF 47MF	10% 20%	50V 1 6V	A A	1014	8-759-908-23 8-759-202-90	IC MB88303					M G
	C1 00 C1 01	1 -1 36-1 53-00	7164	0.01 MF	5%	507	A	1016	8-759-202-56	IC TC74HC245P					J
	C1 02 C1 03 C1 04	1 -1 36-1 53-00 1 -1 36-1 53-00 1 -1 36-1 53-00	フィルム	0.01 MF 0.01 MF 0.01 MF	5% 5% 5%	50V 50V 50V	A A A	1018	8-759-91 4-03	IC SN74LS06N			*		F
		1 -1 36-1 53-00	7111	0.01 MF	5%	50V	Α		<u> 1711,</u>						
	C1 05 C1 06 C1 07	1 -1 36-1 53-00 1 -1 36-1 53-00	フルム	0.01 MF 0.01 MF	5% 5%	50V 50V	A	L1 L1 00	1 -408-421-00 1 -408-409-00	7170 109"79- 7170 109"79-	1 00UH 1 0UH				A B
	C1 08 C1 09	1 -1 36-1 53-00 1 -1 36-1 53-00		0.01 MF 0.01 MF	5% 5%	50V 50V	Ā			<u>97″29</u> "					
		9 14	<u> </u>					Q1 Q2 Q3	8-729-901 -57	トランシ [™] ズタ 2SA117 トランシ [™] ズタ DTC143 トランシ [™] ズタ DTC143	BXS				A A
	D1 D2 D3	8-71 9-91 1 -1 9 8-71 9-91 1 -1 9 8-71 9-91 1 -1 9	タ"イオート" 1:	SS1 1 9			A A A	Q4 Q5 Q6	8-729-903-02 8-729-903-02	トランシ [™] スタ DTA1 4.5 トランシ [™] スタ DTA1 4.5 トランシ [™] スタ DTA1 4.5	3XS 3XS				
	D4 D5 D6	8-71 9-91 1 -1 9 8-71 9-1 04-1 0 8-71 9-91 1 -1 9	タ"イオート" 1:	SS99			A B A	Q7 Q8 Q9	8-729-903-02 8-729-901-57	トランシ [™] スタ DT A1 43 トランシ [™] スタ DT C1 43 トランシ [™] スタ DT C1 43	BXS BXS				A A
	D14 D15	8-71 9-91 1 -1 9 8-71 9-91 1 -1 9	9"YX-1" 1:	SS1 1 9			A	Q1 O	8-729-901 -57	1505"Z9 DTC1 43	BXS				A
	D16	8-71 9-91 1 -1 9	9"17-1" 1	SSI 1 9			Α		713	,					
	D17 D18 D19	8-71 9-1 09-89 8-71 9-1 09-89 8-71 9-1 09-89	9"17-1" R	05.6ES-B2				R1 R2 R3	1 -249-429-11 1 -247-81 5-00 1 -249-429-11	ー カーホ ~ン カーホ~ン	1 0K 5 220 5 1 0K 5		1 /6W 1 /6W 1 /6W		A A A



	*** D - 1'	- m - 2			(本 本	/ 基 校	回声等导	故見っこと	部品名			准女	/巫 ±々
図面番号	部品コード	部品名			備考	1111/16	<u>凶即會亏</u>	部品コード	<u>a) an 15</u>			備考	価格
R4 R5 R6	1-249-434-11 1-249-429-11 1-249-429-11	カーホ"シ カーホ"シ カーホ"シ	27K 1 0K 1 0K	5% 5% 5%	1 /6W 1 /6W 1 /6W	A A	C4 C5 C6	1 -1 02-858-00 1 -1 02-947-00 1 -1 1 0-208-00	セジック 10		0.5PF 5% 5%	50V 50V 50V	A A A
R7 R8 R9	1-249-41 7-1 1 1-247-903-00 1-249-41 7-1 1	カーホ "シ カーホ"シ カーホ "シ	1K 1M 1K	5% 5% 5%	1 /6W 1 /6W 1 /6W	A A	C8 C9 C1 0	1 -1 36-1 53-00 1 -1 36-1 65-00 1 -1 36-1 53-00	フィルム 0.	OIMF IMF OIMF	5% 5% 5%	50V 50V 50V	A A A
R1 0 R1 1 R1 2	1 -249-435-1 1 1 -249-435-1 1 1 -247-851 - 00	カーホ "ン カーホ "ン カーホ "ン	33K 33K 6.8K	5% 5% 5%	1 /6W 1 /6W 1 /6W	A A	CI 1 CI 2 CI 3	1 -1 24-233-00 1-1 24-233-00 1 -1 02-961 -00	テ"ンカイ 10	4F	20% 20% 1 0%	1 6V 1 6V 50V	A A A
R1 3 R1 4 R1 5	1-249-425-11 1-247-851 -00 1-249-425-11	カーホ "ン カーホ "ン カーホ "ン	4.7K 6.8K 4.7K		1 /6W 1 /6W 1 /6W	A A		1 -1 36-1 53-00 1 -1 36-1 53-00 1 -1 36-1 53-00	711,4 0.	01 MF 01 MF 01 MF	5% 5% 5%	50V 50V 50V	A A A
R1 6 R1 7 R1 8	1-247-81 5-00 1-247-81 5-00 1-247-81 5-00	カーホ "ン カーホ "ン カーホ "ン	220 220 220	5% 5% 5%	1 /6W 1 /6W 1 /6W	A A	CI 05	1 -1 36-1 53-00 1 -1 36-1 53-00 1 -1 36-1 53-00	711,4 0.	OIMF OIMF OIMF	5% 5% 5%	50V 50V 50V	A A A
R1 9	1-247-81 5-00		220	5%	1 /6W	Α	CI 07	1 -1 36-1 53-00	フィリム 0:0	OI MF	5%	50V	Α
R20 R21	1-249-429-11 1-249-429-11	カーホ [™] ン カーホ [™] ン	1 OK 1 OK	5% 5%	1 /6W 1 /6W	A		9 4	" 1-t"				
R22	1-249-429-11	カーホーン	1 0K	5%	1 /6W	A	DI		9"17-1" 1 SS11				A
R23 R24	1-249-429-11 1-247-81 5-00	カーホッカーホッ	1 0K 220	5% 5%	1 /6W 1 /6W	A	D2	8-719-911-19 <u>IC</u>	9"Y7-1" 1 SSI	9			Α
R25	1-247-81 5-00		220	5%	1 /6W	A	1.01						
R26 R27	1-247-81 5-00 1-247-81 5-00	カーホ"ン	220 220	5% 5%	1 /6W 1 /6W	A	1C1 1C2 1C3	8-759-203-36	1C TC74HC374F 1C TC74HC374F 1C TC74HC374F	•			J J
R28	1-247-81 5-00	カーホ [™] ン カーホ [™] ン	220	5% 5%	1 /6W	A	104	0 750 202 26	10 707410374				
R29 R30	1-249-441-11 1-247-815-00	カーホ"ン	1 00K 220	5%	1 /6W	A	1C4 1C5 1C6	8-759-203-61	1C TC74HC374F 1C TC74HC688F 1C TC74HC688F	•			j J
R31 R3 <i>2</i>	1 -249-429-1 1 1-249-429-1 1	カーホ [™] ン カーホ [™] ン	1 0K 1 0K	5% 5%	1 /6W 1 /6W	A A	IC7	8-750-203-68	1C TC74HC404	20			н
R33	1-249-429-11	カーホ"ン	1 OK	5%	1 /6W	Â	1C8 1C9		IC TC74HC404				H Q
R34 R35	1-247-81 5-00 1-247-81 7-00	カーホック	220 270	5% 5%	1 /6W 1 /6W	A	1010	8-759-107-33	LC UPOL060C				.1
R36	1-247-887-00	カーホ"ン	220K		1 /6W	Ā	ICI 1 ICI 2	8-759-202-15 8-759-202-11	IC TC74HC1 OP				D D
		テイコウ					IC1 3	8-759-202-1 2	IC TC74HC02P				D
RV1	1-228-305-00	サーメット ハンコテイ ラ	イコウ 1K			F	ICI 4 ICI 5	8-759-990-82 8-759-20 <i>2</i> -86		•			F H
****							IC16	8-759-202-86	1 C TC74HC1 23F	•			Н
	*A-1 1 35-41 9-A	マかトスで BO もり	1"5					<u>713</u>	2				
	<u> </u>	79-					R1 R2	1 -249-425-11 1 -215-457-00	キンに [®]		5% 1/ 1% 1/		A A
BO1 BO2 BO3	*1-563-01 7-1 1 *1-563-01 7-1 1 *1-564-458-1 1		- 30P	IMC°"5) 10P	E C	R3 .	1-249-417-11	カーホッン	1 K 1 M	5% 1/ 5% 1/	бW бW	A A
	<u> 107</u>	"של" –						1 -247-81 5-00 1 -249-441 -11	カーホ "ン カーホ "シ	220 1 00K	5% 1/ 5% 1/		A A
C1 C2 C3	1-1 02-848-00 1-1 02-676-00 1-1 02-858-00	セラミック 68P	F	5% 5% 0.56	50V 50V PF 50V	A A A	R1 1	1 -21 5-428-00 1 -21 5-469-00 1 -21 5-430-00	キンじ [®] キンじ [®] キンじ [®]	2K 1 00K 2 . 4K		Б₩	A A A

図面番号	部品コード	部品名			備考	価格	図面番号	部品コード	部品名	<u>3</u>		備考	価格
R1 3 R1 4 R1 5	1 -21 5-430-00 1 -21 5-423-00 1 -21 5-430-00		2.4K 1; 1.2K 1; 2.4K 1;	\$ 1 <i>/</i>	бพ	A A	C24 C25 C26	1 -1 36-1 65-00 1 -1 36-1 65-00 1 -1 36-1 65-00	フィルム	0.1MF 0.1MF 0.1MF	5% 5% 5%	50V 50V 50V	A A A
R1 6 R1 7 R1 8	1-21 5-4 31-00 1-21 5-4 44-00 1-21 5-4 28-00	も)た。 も)た。 も)た。	2.7K 1; 9.1K 1; 2K 1;	1/	6W	A A A	C27 C28 C29	1 -1 36-1 65-00 1 -1 36-1 65-00 1 -1 36-1 65-00	フィルム	0.1MF 0.1MF 0.1MF	5% 5% 5%	50V 50V 50V	A A A
R1 9 R20	, 2,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	もうしゃ	2K 1; 3.6K 1;		6W	A	C30 C1 00 C1 01	1 -1 1 0-1 95-00 1 -1 24-236-00 1 -1 36-1 53-00	デ゙ンカイ	0.001 MF 47MF 0.01 MF	5% 20% 5%	50V 16V 50V	A A A
	<u>かへつ</u>	テイコウ					C1 02	1-136-153-00	フィルム	0.01MF	5%	.50V	Α
RVI RV2 RV3	1 -228-31 0-00 1 -228-308-00 1 -228-304-00	サーメツト ハンコ	テイ テイコウ 10K			F F	C200 C201	1 -1 36-1 53-00 1 -1 36-1 53-00	フィッム フィッム	0.01 MF 0.01 MF	5% 5%	50V 50V	A A
	24:	ヨウ ハツシンシ					C202 C203	1 -1 36-1 53-00 1 -1 36-1 53-00		0.01MF 0.01MF	5% 5%	50V 50V	A A
			W4 -			М	C204	1 -1 36-1 53-00		0.01 MF	5%	50.V	Α
Χ1	1 -567-1 35-00							1-136-153-00		0.01MF	5% 5%	50V	A
*****	*****	*****	*****	*****	******	****	C301 C302	1 -1 36-1 53-00 1 -1 36-1 53-00		0.01 MF 0.01 MF	5% 5%	50 V 50 V	A A
	*A-1 1 35-420-A	*****	*****			_	C303 C304	1-136-153-00 1-136-153-00	フィルム	0.01MF 0.01MF	5% 5%	50V 50V 50V	A A A
	*1 -563-01 7-1 1 *1 -566-054-1 1 *1 -566-060-1 1	בא"פ <i>פ</i> "מב	コネクター 30P ヨウ コネクタ に°ン ヨウ コネクタた°ン 8	2P P		E A A	C305		" -1-k	0.01MF	5%	۷۵۷	^
	4-353-708-00	フィンカ- フツ	2			Α	D1	8-71 9-91 1 -1 9 8-71 9-91 1 -1 9	タ"イオート" 1	SS119			A A
	<u> </u>	<u>"דיכ" -</u>			•		D2 D3	8-71 9-91 1 -1 9	タ"イオート" 1	SS119			Ä
C1 C2 C3	1 -1 36-1 53-00 1 -1 24-233-00 1 -1 36-1 53-00	テ "ンカイ	0.01 MF 1 OMF 0.01 MF	5% 20% 5%	50V 16V 50V	A A A	D4 D5 D6	8-71 9-91 1 -1 9 8-71 9-91 1 -1 9 8-71 9-91 1 -1 9	タ"イオート" 1	SSI 1 9			A A A
C4 C5 C6	1 -1 24-233-00 1 -1 02-858-00 1 -1 36-1 53-00	セジミツク	1 OMF 1 OPF 0 .01 MF	20% 0.5PF 5%	1 6V 50V 50V	A A A	D7	8-71 9-91 1 -1 9 <u>IC</u>	9"イオート" 1	SS119			A
C7 C8 C9	1 -1 36-1 53-00 1 -1 02-884-00 1 -1 24-233-00	セラミツク	0.01MF 33PF 10MF	5% 5% 20%	50V 50V 1 6V	A A A	1C1 1C2 1C3	8-759-240-53 8-759-990-82 8-759-602-33	IC TL0820	ዖ			F F F
C1 0 C1 1 C1 2	1 -1 36-1 59-00 1 -1 36-1 59-00 1 -1 36-1 59-00	フルム	0.033MF 0.033MF 0.033MF	5% 5% 5%	50V 50V 50V	A A A	1C4 1C5 1C6	8-759-240-53 8-759-202-94 8-759-1 07-35	IC TC74HC	1 54P			F G M
C1 3 C1 4 C1 5	1 -1 36-1 59-00 1 -1 36-1 65-00 1 -1 36-1 59-00	フィルム	0.033MF 0.1MF 0.033MF	5% 5% 5%	50V 50V 50V	A A A	1C7 1C8 1C9	8-759-1 07-35 8-759-1 07-35 8-759-990-62	IC UPD520	01 C			M M H
C1 6 C1 7 C1 8	1 -1 36-1 59-00 1 -1 36-1 59-00 1 -1 36-1 59-00	7116	0.033MF 0.033MF 0.033MF	5% 5% 5%	50V 50V 50V	A A A	1C1 0 1C11 1C1 2	8-759-990-62 8-759-990-62 8-759-990-62	IC TL0620 IC TL0620 IC TL0620	ያ			н н
C1 9 C20 C21	1 -1 36-1 65-00 1 -1 36-1 59-00 1 -1 36-1 59-00	フィルム	0.1 MF 0.033MF 0.033MF	5% 5% 5%	50V 50V 50V	A A A	ICI 3 ICI 4 ICI 5	8-759-990-62 8-759-990-62 8-759-1 07-35	IC TL0620 IC TL0620 IC UPD520	ዖ			H H M
C22 C23	1 -1 36-1 59-00 1 -1 36-1 59-00		0.033MF 0.033MF	5% 5%	50V 50V	A A	1C16 1C17 1C18	8-759-1 07-35 8-759-1 07-35 8-759-1 07-35	IC UPD520 IC UPD520 IC UPD520	01 C			М М М

BP

図面番号	部品コード	部品名		備考	価格	図面番号	部品コード	部品名				備考	価格
1C1 9 1C20 1C21	8-759-1 03-06	IC UPD5201 C IC UPC398C IC TL0820P			M K F	R24 R25 R26	1 -249-429-1 1 1 - 247-839-00 1 - 249-423-1 1	カーホ "ン カーホ "ン カーホ "ン	1 0K 2.2K 3.3K	5% 5% 5%	1 /6W 1 /6W 1 /6W		A A A
1C22 1C23	8-759-202-11	IC TL082CP IC TC74HC00P			F D	R27 R28 R29	1-247-839-00 1-249-429-11 1-249-425-11	カーホ "シ カーホ "シ カーホ "シ	2.2K 1 0K 4.7K	5% 5% 5%	1 /6W 1 /6W 1 /6W		A A A
	<u> 1711,</u>					R30	1-249-422-11	カーホ "ン	2.7K	5%	1 /6W		Α
L1 L2 L1 00	1-408-533-00 1-408-429-00 1-408-409-00	71 90 109 109-	470UH 1 OUH		B A B	R31 R32	1 -249-425-11 1-249-433-11	カーホ "ン カーホ "ン	4.7K 22K	5% 5%	1 /6W		A A
		- 11-20				R33	1-249-425-11	カーホーン	4.7K	5%	1 /6W		A
	199	<i>5[™]79</i>				R34 R35	1-249-420-11	カーホーン	1.8K 100K	5% 5%	1 /6W 1 /6W		A A
Q1 Q2	8-729-601 -47	トランシ"スタ 2SA1175 トランシ"スタ 2SK381 -	В		A	R36	1-249-422-11	カーホ "ン	2.7K	5%	1 /6W		A
Q3	8-729-800 - 1 O	トランシ <i>"スタ</i> 2SC3068	•		₿	R37 R38	1 -249-441 -11	カーホ "ン カーホ "ン	100K 100K	5% 5%	1 /6W 1 /6W		A
04	8-729-1 78-54	トランシ [™] スタ 2SC2785	i		Α	1133			1001	7,0	1 /011		^
Q 5	8-729-1 78-54	トランシ [™] スタ 2SC2785			A	R39		カーホーン	2.2K	5%	1 /6W		A
Q6	8-729-1 78-54	トランシ [™] ズタ 2SC2785	•		Α	R40 R41	1 - 247 - 839 - 00 1 - 21 4 - 71 3 - 00	カーホ [™] ン キンに [®]	2.2K 220	5% 1%	1 /6W 1 /4W		A A
07	8-729-601 -47	וליכיכו 2SK381 -	В		Α						.,		••
Q8	8-729-1 78-54	トランシ [™] スタ 2SC2785			A	R42	1-249-437-11	カーホ "ン カーホ"ン	47K	5%	1 /6W		A
Q9	8-729-601 -47	トランシ [™] スタ 2SK381 -	8		Α	R43 R44	1-249-437-11	カーホーン	47K 10K	5% 5%	1 /6W 1 /6W		A A
Q1 O	8-729-1 78-54	トランシ"スタ 2SC2785	,		Α		1-243-425-11				. / 5.11		
Q1 1	8-729-1 78-54	トランシ [™] スタ 2SC2785			Α	R45	1-249-437-11	カーホーン	47K	5%	1 /6W		A
Q1 2	8-729-117-54	トランシ"スタ 2SA1175	i		Α	R46	1 -249-437-11 1 -249-429-11	カーホ [™] ン カーホ [™] ン	47K 10K	5% 5%	1 /6W		A A
01 3	8-729-901 -57	トランシ [™] スタ DTC1 43X	S		Α	1 177	1-245-425-11		101	70	1 /011		^
Q1 4	8-729-903-02	トランシ [™] スタ DTA1 43X	S			R48	1-249-429-11	カーホ "ン	1 OK	5%	1 /6W		Α
	テイニ	ı ò				R49 R50	1 -249-429-11 1 -249-429-11	カーホ "ン カーホ "ン	10K 10K	5% 5%	1 /6W 1 /6W		A
	51.	12				1,50	1-243-423-11		101	70	1 /011		^
R1	1-249-422-11		.7K 5%	1 /6W	Α	R51	1 -249-429-11	カーホッン	1 0K	5%	1 /6W		A
R2	1-249-422-11		2.7K 5% 2K 5%	1 /6W 1 /6W	A A	R52 R53	1 - 249 - 429 - 11 1 - 249 - 425 - 11	カーホ "ン カーホ"ン	10K 4.7K	5% 5%	1 /6W 1 /6W		A A
R3	1-249-433-11	7)-11 2	21 20	1 /011	^	K25.	1-243-425-11	77-111 3	4.71	70	1 /01		^
R4	1-249-429-11		OK 5%	1 /6W	Α	R54	1-215-457-00	もした。	33K	18	1 /6W		Α
R5	1-249-422-11		2.7K 5%	1 /6W	A	R55 R60	1 -21 5-427-00 1-247-862-00	キンに [®] カ ー ホ [™] ン	1.8K 20K	1 % 5%	1 /6W		A A
R6	1-249-422-11	/J-N-J 2	2. /K 5%	1 /6W	Α	ROU	1-247-802-00	73-111 3	201	۵٫۵	1 /0#		^
R7	1-249-429-11	カーホーン 1	OK 5%	1 /6W	Α	R61	1 -21 5-397-00	キンヒ [°]	100	1%	1 /6W		Α
R8	1-249-405-11	カーホ"ン 1	00 5 % 270 5 %	1 /6W	A	R62 R64	1 -21 5-469-00 1 -249-41 7-1 1	キンに [®] カーホ [™] ン	100K 1K	1 % 5%	1 /6W 1 /6W		A A
R9	1-247-81 7-00	/3-m /3 /2	هر ۱۰	1 /6W	Α	704	1-243-417-11	7,-11 3	110	76	1 /011		^
R1 0	1-249-425-11		.7K 5%	1 /6W	Α	R65	1-247-700-11	カーホ "ン	100	5%	1 /4W		A
R1 1	1-249-425-11		.7K 5%	1 /6W	A	R66	1-249-423-11	カーホーン	3.3K		1/6W		A
R1 3	1-249-441-11	カーホン	00K 5%	1 /6W	Α	R67	1 -247-903-00	カーホーン	1 M	5%	1 /6W		Α
R1 4	1-247-849-00	カーホ"ン 5	.6K 5%	1 /6W	Α		かへご	テイコウ					
	1-249-41 7-1 1	カーホッン	K 5%	1 /6W	A								
R1 6	1-249-425-11	カーホーン 4	.7K 5%	1 /6W	Α	RV1 RV2		サーメツト ハンコテイ デ サーメツト ハンコテイ デ					F F
R1 7	1-249-405-11	カーホ "ン 1	00 5%	1 /6W	Α	1112	, 220 307 00	110-111	//				'
R1 8	1-249-425-11		.7K 5%	1 /6W	A		スイツ	<u> </u>	•				
R1 9	1-249-429-11	カーホ "ン 1	OK 5%	1 /6W	Α	SI	1-554-076-00	スライト** マイッチ					С
R20	1-247-839-00	カーホーン 2	.2K 5%	1 /6W	Α	3,	. 224-070-00	7711 7177					•
R21	1-249-429-11	カーホ "ン 1	OK 5%	1 /6W	Α								
R22	1-249-425-11	カーホ"ン 4	.7K 5%	1 /6W	Α								
R23	1-249-425-11	カーホ "ン 4	.7K 5%	1 /6W	Α								

8-5(J)

SECTION 8 ELECTRICAL PARTS LIST



Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

When indicating parts by reference number, please include the board name.

All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

CAPACITORS • MF : μF, PF : μμF RESISTORS

COILS • MMH : mH, UH : μH

• All resistors are in ohms
• F : nonflammable

Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description				Remark
	*A-1135-418-A	BN BOARD, CO				D23 D24	8-719-109-89 8-719-911-19	DIODE RD5.6ES- DIODE 1SS119	-B2			
	*1-528-166-11 *1-563-017-11 *1-564-460-41 *2-378-216-01 *4-353-708-00	CONNECTOR, F	.P.C. 30P TOR (2.5MM) RY			I IC1	E-759-925-44 1-526-662-21 8-759-925-45 1-526-662-21	IC LH5080L SOCKET, IC (D IC LH5081L SOCKET, IC (D				
	CAP	AC I TOR				IC3	8-759-746-63	IC MBM27C256-				
C1 C2 C3 C4 C5	1-124-255-00 1-136-153-00 1-124-249-00 1-124-249-00 1-102-863-00	FILM ELECT ELECT	1MF 0.01MF 0.1MF 0.1MF 82PF	20% 5% 20% 20% 5%	50V 50V 50V 50V 50V	 IC4 IC5 IC6	1-526-659-00 8-759-301-62 1-526-659-00 8-759-202-11 8-759-202-86	SOCKET, IC (D IC HM6264P-12 SOCKET, IC (D IC TC74HC00P IC TC74HC123P	P) 28P			
C6 C7 C8 C9 C10	1-102-676-00 1-110-195-00 1-110-199-00 1-136-165-00 1-124-255-00	MYLAR	68PF 0.001MF 0.0022MF 0.1MF 1MF	5% 5% 5% 5% 20%	50V 50V 50V 50V 50V	IC7 IC8 IC9 IC10 IC11	8-759-202-94 8-759-908-35 8-759-202-74 8-759-202-11 8-759-203-36	IC TC74HC154P IC TL7705CP-B IC TC74HC04P IC TC74HC00P IC TC74HC374P				
C 11 C 12 C 13 C 14 C 15	1-124-255-00 1-124-255-00 1-102-887-00 1-124-255-00 1-161-039-00	ELECT CERAMIC ELECT	1MF 1MF 47PF 1MF 0.001MF	20% 20% 5% 20% 10%	50V 50V 50V 50V 25V	IC12 IC13 IC14 IC15 IC16	8-759-908-23 8-759-202-90	IC TC74HC374P IC TC74HC374P IC MB88303 IC TC74HC147P IC TC74HC245P				
C 16 C 100 C 101 C 102 C 103	1-102-973-00 1-124-236-00 1-136-153-00 1-136-153-00 1-136-153-00	ELECT FILM FILM	100PF 47MF 0.01MF 0.01MF 0.01MF	10% 20% 5% 5% 5%	50V 16V 50V 50V 50V	IC17 IC18 		IC TC74HC245P IC SN74LS06N				
C104 C105 C106 C107 C108	1-136-153-00 1-136-153-00 1-136-153-00 1-136-153-00 1-136-153-00	FILM FILM FILM FILM	0.01MF 0.01MF 0.01MF 0.01MF 0.01MF	5% 5% 5% 5%	50V 50V 50V 50V 50V	L1 L100 Q1	1-408-409-00 TRA	MICRO INDUCTO MICRO INDUCTO MSISTOR TRANSISTOR 2S	R 10UH			
C109	1-136-153-00		0.01MF	5%	50V	i 02 i 03	8-729-901-57 8-729-901-57	TRANSISTOR DT TRANSISTOR DT				
CIU		ODE				Q4 Q5	8-729-903-02 8-729-903-02	TRANSISTOR DT TRANSISTOR DT				
D1 D2 D3 D4 D5	8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19 8-719-104-10	DIODE 1SS119 DIODE 1SS119 DIODE 1SS119	9			Q6 Q7 Q8 Q9 Q10	8-729-901-57 8-729-901-57	TRANSISTOR DT TRANSISTOR DT	A143XS C143XS C143XS			
D6	8-719-911-19	DIODE 1SS119	9				RES	SISTOR				
D14 D15 D16 D17	8-719-911-19 8-719-911-19 8-719-911-19 8-719-109-89	DIODE 155119 DIODE RD5.68	9 9 ES-B2			R1 R2 R3 R4	1-249-429-11 1-247-815-00 1-249-429-11 1-249-434-11	CARBON CARBON CARBON	10K 220 10K 27K	5% 5% 5%	1/6W 1/6W 1/6W 1/6W	
D 18 D 19 D 20 D 21 D 22	8-719-109-89 8-719-109-89 8-719-109-89 8-719-109-89 8-719-109-89	DIODE RD5.68	ES-B2 ES-B2 ES-B2			R5 R6 R7 R8 R9	1-249-429-11 1-249-417-11 1-247-903-00 1-249-417-11	CARBON CARBON	10K 10K 1K 1M 1K	5% 5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W	
						•						



Ref.No.	Part No.	Description				Remark	Ref.No.	Part No.	Description				Remark
R10 R11 R12 R13 R14	1-249-435-11 1-249-435-11 1-247-851-00 1-249-425-11 1-247-851-00	CARBON CARBON CARBON CARBON CARBON	33K 33K 6.8K 4.7K 6.8K	5%	1/6W 1/6W 1/6W 1/6W 1/6W		C13 C101 C102 C103 C104	1-102-961-00 1-136-153-00 1-136-153-00 1-136-153-00 1-136-153-00	FILM FILM FILM	27PF 0.01MF 0.01MF 0.01MF 0.01MF		10% 5% 5% 5% 5%	50V 50V 50V 50V 50V
R15 R16 R17 R18 R19	1-249-425-11 1-247-815-00 1-247-815-00 1-247-815-00 1-247-815-00	CARBON CARBON CARBON CARBON CARBON	4.7K 220 220 220 220 220	5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W		C105 C106 C107	1-136-153-00 1-136-153-00 1-136-153-00	FILM FILM	0.01MF 0.01MF 0.01MF		5% 5% 5%	50V 50V 50V
R20 R21 R22 R23 R24	1-249-429-11 1-249-429-11 1-249-429-11 1-249-429-11 1-247-815-00	CARBON CARBON CARBON CARBON CARBON	10K 10K 10K 10K 220	5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W		D1 D2	8-719-911-19 8-719-911-19 <u>IC</u>	DIODE 1SS119				
R25 R26 R27 R28 R29	1-247-815-00 1-247-815-00 1-247-815-00 1-247-815-00 1-249-441-11	CARBON CARBON CARBON CARBON CARBON	220 220 220 220 220 100K	5% 5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W		IC1 IC2 IC3 IC4 IC5	8-759-203-36 8-759-203-36 8-759-203-36 8-759-203-36 8-759-203-61		P P P			
R30 R31 R32 R33 R34	1-247-815-00 1-249-429-11 1-249-429-11 1-249-429-11 1-247-815-00	CARBON CARBON CARBON CARBON CARBON	220 10K 10K 10K 220	5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W		IC6 IC7 IC8 IC9 IC10	8-759-203-61 8-759-203-68 8-759-203-68 8-759-103-95 8-759-107-33		0P			
R35 R36	1-247-817-00 1-247-887-00	CARBON	270 220K	5%	1/6W 1/6W		IC11 IC12 IC13 IC14 IC15	8-759-202-15 8-759-202-11 8-759-202-12 8-759-990-82 8-759-202-86	IC TC74HC10P IC TC74HC00P IC TC74HC02P IC TL082CP IC TC74HC123	P			
RV1		RES, ADJ, CE	_				I IC16	8-759-202-86	IC TC74HC123	Р			
*****	*****	*****	*****	****	*****	*****		RES	ISTOR				
	*A-1135-419-A	BO BOARD, COI					R1 R2 R3 R4	1-249-425-11 1-215-457-00 1-249-417-11 1-247-903-00	ME TAL CARBON	4.7K 33K 1K 1M	5% 1% 5% 5%	1/6W 1/6W 1/6W 1/6W	
B01 B02 B03	*1-563-017-11 *1-563-017-11 *1-564-458-11	CONNECTOR, F.	.P.C 30	P	10P		R7 R9 R10 R11 R12	1-247-815-00 1-249-441-11 1-215-428-00 1-215-469-00 1-215-430-00		220 100K 2K 100K 2.4K	5% 5% 1% 1%	1/6W 1/6W 1/6W 1/6W 1/6W	
C1	1-102-848-00		180PF		5%	50V	R13	1-215-430-00	METAL	2.4K		1/6W	
C2 C3 C4 C5	1-102-676-00 1-102-858-00 1-102-858-00 1-102-947-00		68PF 10PF 10PF 10PF		5% 0.5PF 0.5PF 5%	50V 50V 50V 50V	R14 R15 R16 R17 R18	1-215-423-00 1-215-430-00 1-215-431-00 1-215-444-00 1-215-428-00	METAL METAL METAL METAL METAL	1.2K 2.4K 2.7K 9.1K 2K	1%	1/6W 1/6W 1/6W 1/6W 1/6W	
C6 C8 C9 C10 C11	1-110-208-00 1-136-153-00 1-136-165-00 1-136-153-00 1-124-233-00	MYLAR FILM FILM FILM ELECT	0.012M 0.01MF 0.1MF 0.01MF	• ,		50V 50V 50V 50V 16V	 R19 R20 		METAL METAL IABLE RESISTO	2K 3.6K	1% 1%	1/6W 1/6W	
C12	1-124-233-00		10MF			16V	i RV1	1-228-310-00		_	K		



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
RV2	1-228-308-00	RES, ADJ, CER	RMET 10K			C203	1-136-153-00		0.01MF	5%	50V
RV3	1-228-304-00	RES, ADJ, CER	RMET 500			C204	1-136-153-00	FILM	0.01MF	5%	50V
	COV	CTAI				C300 C301	1-136-153-00 1-136-153-00	FILM	0.01MF 0.01MF	5% 5%	50V 50V
		STAL				C301	1-136-153-00		0.01MF	5%	50V 50V
X1	1-567-135-00	VIBRATOR, CRY	YSTAL			1 0202	1 126 152 00	ETIM	0 01ME	Eø	50V
. د.	*****	****	*****	*****	******	C303 C304	1-136-153-00 1-136-153-00		0.01MF 0.01MF	5% 5%	50V 50V
*****						C305	1-136-153-00		0.01MF	5%	50V
	*A-1135-420-A	BP BOARD, COM									
							<u>DIO</u>				
	*1-563-017-11					D1	8-719-911-19				
	*1-566-054-11					D2 D3	8-719-911-19 8-719-911-19				
	*1-566-060-11 *4-353-708-00	PIN, CONNECT	UK OF			1 D4	8-719-911-19				
						D5		DIODE 188119			
	CAP	AC I TOR				 D6	8-719-911-19	DIODE 1SS119			
C1	1-136-153-00	FILM	0.01MF	5%	50V	D7	8-719-911-19				
C2	1-124-233-00	ELECT	10MF	20%	16V		ic				
C 3 C 4	1-136-153-00 1-124-233-00	FILM ELECT	0.01MF 10MF	5% 20%	50V 16V	1	IC				
C5	1-102-858-00	CERAMIC	10PF	0.5PF	50V	IC1	8-759-240-53				
				F ~	504	IC2	8-759-990-82				
C6	1-136-153-00		0.01MF	5% 5%	50V 50V	IC3	8-759-602-33 8-759-240-53	IC CX20197 IC TC4053BP			
C7	1-136-153-00 1-102-884-00	FILM CERAMIC	0.01MF 33PF	5% 5%	50V 50V	I IC5	8-759-202-94	IC TC74HC154	P		
C8 C9	1-124-233-00	ELECT	10MF	20%	16V				170		
C10	1-136-159-00	FILM	0.033MF	5%	50V	IC6	8-759-107-35				
		57. W	0.02245	E e/	EOV	I IC7	8-759-107-35 8-759-107-35	IC UPD5201C			
C11	1-136-159-00		0.033MF 0.033MF	5% 5%	50V 50V	IC8	8-759-990-62				
C 12 C 13	1-136-159-00 1-136-159-00		0.033MF	5%	50V	ICIO	8-759-990-62				
C14	1-136-165-00	FILM	0.1MF	5%	50V	İ					
C 15	1-136-159-00	FILM	0.033MF	5%	50V	I IC11	8-759-990-62	IC TLO62CP			
	1 100 150 00	CT: M	U USSME	5%	50V	IC12 IC13	8-759-990-62 8-759-990-62	IC TLO62CP IC TLO62CP			
C16	1-136-159-00 1-136-159-00		0.033MF 0.033MF	5% 5%	50V 50V	IC14	8-759-990-62	IC TLO62CP			
C17 C18	1-136-159-00		0.033MF	5%	50V	IC15	8-759-107-35	IC UPD5201C			
C19	1-136-165-00	FILM	0.1MF	5%	50V	1	0.750.107.05	TO UDD 50010			
C 20	1-136-159-00	FILM	0.033MF	5%	50V	IC16	8-759-107-35 8-759-107-35	IC UPD5201C IC UPD5201C			
C 01	1 126 150 00	FTIM	0.033MF	5%	50V	IC17 IC18	8-759-107-35	IC UPD5201C			
C21 C22	1-136-159-00 1-136-159-00		0.033MF	5%	50V	IC19	8-759-107-35	IC UPD5201C			
C23	1-136-159-00		0.033MF	5%	50V	IC20	8-759-103-06	IC UPC398C			
C 24	1-136-165-00	FILM	0.1MF	5%	50V	1 1021	8-759-990-82	TO THE DESCR			
C 25	1-136-165-00	FILM	0.1MF	5%	50V	IC21 IC22	8-759-990-82	IC TLOSZCP			
C 26	1-136-165-00	FILM	0.1MF	5%	50V	IC23		IC TC74HC00F)		
C 27	1-136-165-00	FILM	0.1MF	5%	50V	!	201	11			
C 28	1-136-165-00		0.1MF	5% 5*	50V 50V	-	<u>C0</u> 1	<u>L</u>			
C 29	1-136-165-00 1-110-195-00		0.1MF 0.001MF	5% 5%	50V 50V	11	1-408-533-00	COIL, VARIAB	BLE		
C 30						L2	1-408-429-00	MICRO INDUCT	OR 470UH		
C100	1-124-236-00		47MF	20%	160	L100	1-408-409-00	MICRO INDUCT	OR 10UH		
C101	1-136-153-00		0.01MF 0.01MF	5% 5%	50V 50V	1	TRA	ANSISTOR			
C102	1-136-153-00 1-136-153-00		0.01MF	5% 5%	50V 50V	i	11/				
C 200 C 201	1-136-153-00		0.01MF	5%	50V	į Q1	8-729-117-54	TRANSISTOR 2			
3201					FOU	Q2	8-729-601-47	TRANSISTOR 2			
C 202	1-136-153-00	FILM	0.01MF	5%	50V.	Q3 Q4	8-729-800-10 8-729-178-54	TRANSISTOR 2			
						ו עד	5-125-110-54				



Ref.No.	Part No.	Description				Remark	Ref.No.	Part No.	Description				Remark
Q5 Q6 Q7 Q8 Q9	8-729-178-54 8-729-178-54 8-729-601-47 8-729-178-54 8-729-601-47	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SC2785 2SK381 -B 2SC2785				R43 R44 R45 R46 R47	1-249-437-11 1-249-429-11 1-249-437-11 1-249-437-11 1-249-429-11	CARBON CARBON CARBON	47K 1 OK 47K 47K 10K	5% 5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W	
Q10 Q11 Q12 Q13 Q14	8-729-178-54 8-729-178-54 8-729-117-54 8-729-901-57 8-729-903-02	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SC2785 2SA1175 DTC143XS				R48 R49 R50 R51 R52	1-249-429-11 1-249-429-11 1-249-429-11 1-249-429-11 1-249-429-11	CARBON CARBON CARBON	10K 10K 10K 10K 10K	5% 5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W	
	RES	ISTOR					 R53	1-249-425-11		4.7K	5%	1/6W	
R1 R2 R3 R4	1-249-422-11 1-249-422-11 1-249-433-11 1-249-429-11	CARBON CARBON CARBON CARBON	2.7K 2.7K 22K 10K		1/6W 1/6W 1/6W 1/6W		R54 R55 R60 R61	1-215-457-00 1-215-427-00 1-247-862-00 1-215-397-00	METAL METAL CARBON METAL	33K 1.8K 20K 100	1% 1% 5% 1%	1/6W 1/6W 1/6W 1/6W	
R5 R6 R7 R8	1-249-422-11 1-249-422-11 1-249-429-11 1-249-405-11	CARBON CARBON CARBON CARBON	2.7K 2.7K 10K 100	5% 5% 5% 5%	1/6W 1/6W 1/6W 1/6W		R62 R64 R65 R66 R67	1-215-469-00 1-249-417-11 1-247-700-11 1-249-423-11 1-247-903-00	CARBON CARBON	100K 1K 100 3.3K 1M	1% 5% 5% 5% 5%	1/6W 1/6W 1/4W 1/6W 1/6W	А
R9 R10	1-247-817-00 1-249-425-11	CARBON CARBON	270 4.7K	5% 5%	1/6W 1/6W				IABLE RESISTOR	₹			
R11 R13 R14 R15	1-249-425-11 1-249-441-11 1-247-849-00 1-249-417-11	CARBON CARBON CARBON CARBON	4.7K 100K 5.6K 1K	5%	1/6W 1/6W 1/6W 1/6W		RV1 RV2	1-228-307-00	RES, ADJ, CER RES, ADJ, CER				
R16	1-249-425-11	CARBON	4.7K		1/6W		j I S1		 SWITCH, SLIDE				
R17 R18 R19 R20 R21	1-249-405-11 1-249-425-11 1-249-429-11 1-247-839-00 1-249-429-11	CARBON CARBON CARBON CARBON CARBON	100 4.7K 10K 2.2K 10K	5%	1/6W 1/6W 1/6W 1/6W 1/6W		 ***** 	********** *1-620-471-11	*****		****	*****	******
R22 R23 R24 R25 R26	1-249-425-11 1-249-425-11 1-249-429-11 1-247-839-00 1-249-423-11	CARBON CARBON CARBON CARBON CARBON	4.7K 4.7K 10K 2.2K 3.3K	5% 5% 5%	1/6W 1/6W 1/6W 1/6W 1/6W			4-379-004-01 4-379-004-11 4-379-004-21 4-379-004-31 4-379-004-41	KEY TOP KEY TOP KEY TOP				
R27	1-247-839-00	CARBON	2.2K		1/6W			CAP	ACITOR				
R28 R29	1-249-429-11	CARBON CARBON CARBON	10K 4.7K 2.7K		1/6W 1/6W 1/6W		C1	1-136-153-00	FILM	0.01MF		5%	50 V
R30 R31	1-249-422-11 1-249-425-11	CARBON	4.7K		1/6W			CON	NECTOR				
R32 R33 R34 R35	1-249-433-11 1-249-425-11 1-249-420-11 1-249-441-11	CARBON CARBON CARBON CARBON	22K 4.7K 1.8K 100K	5% 5%	1/6W 1/6W 1/6W 1/6W		HE2 HE3 HE4	*1-564-448-11	RECEPTACLE, C	ONNECT	OR 12	•	
R36	1-249-422-11		2.7K		1/6W			<u>IC</u>	T: 2550				
R37 R38	1-249-441-11	CARBON CARBON	100K 100K	5%	1/6W 1/6W		IC1	8-719-801-77					
R39 R40 R41	1-247-839-00 1-247-839-00 1-214-713-00	CARBON CARBON METAL	2.2K 2.2K 220		1/6W 1/6W 1/4W		 R1	RES 1-249-429-11	ISTOR CARBON	10K	5%	1/6W	
R42	1-249-437-11	CARBON	47K	5%	1/6W		l R2 l	1-249-415-11	CARBON	680	5%	1/6W	

Ref.No.	Part No.	Description	Remark
	SW	ITCH	
S3	1-554-724-11 1-554-724-11 1-554-724-11	SWITCH, PUSH (1 KEY) SWITCH, PUSH (1 KEY) SWITCH, PUSH (1 KEY) SWITCH, PUSH (1 KEY) SWITCH, PUSH (1 KEY)	
*****	*****	*********	******
		SCELLANEOUS	
		WIRE, FLEXIBLE (1.25 PITCH) LABEL, MODEL NUMBER SUPPORT	
*****	*****	*******	******
		ORIES AND PACKING MATERIALS	
	Part No.	Description	Remark

Part No.	Description	Remark
*1-558-919-11 2-112-739-01 *2-112-740-01 *2-112-753-01 *2-112-754-01	WIRE, FLEXIBLE (1.25 PITCH) MANUAL, OPERATION MAINTENANCE COVER, PC BOARD CUSHION (A) CUSHION (B)	
*2-112-755-01 *2-112-756-01	CUSHION (C) INDIVIDUAL CARTON	